

1

Install the Pro Power Kit



ring

The Pro Power Kit is required to power your Ring Doorbell Pro.



## Welcome

Hi, I'm Jamie Siminoff,  
inventor of your Ring  
Video Doorbell.

Congratulations on  
purchasing the world's  
most advanced doorbell!

With Ring, you'll always  
know who's at your door,  
whether you're across  
town, on vacation, or just  
can't come to the door. As  
my wife likes to say, "Ring  
is like caller ID for the front  
door."



## Installing the Pro Power Kit


Working with your doorbell's wires might seem intimidating, but installation is easy!

We'll walk you through every step, and if you need extra help you can always give us a call.

Online Help Center:  
[ring.com/help](https://ring.com/help)

Ring Community Support:  
[us 800.656.1918](tel:800.656.1918)  
[Worldwide +1 310.929.7085](tel:+1310.929.7085)  
[help@ring.com](mailto:help@ring.com)

## Pro Power Kit





## Step 1

### Download the Ring app

The Ring app will walk you through the setup and installation processes.

The app is available for iOS, Android, Mac Desktop, and Windows 10.



**Search for “Ring” in one of the app stores above, or visit: [ring.com/app](https://ring.com/app)**




We have an online guide with videos and tutorials at: [ring.com/setup](https://ring.com/setup)

## Step 2

Remove the cover on your internal doorbell.

Before touching the wires inside your doorbell, shut off power at the breaker.




## Step 3

### Disconnect your doorbell's "Front" wire

Look for wires labeled "Front" and "Transformer."


Loosen the screw on "Front" and disconnect the wire.




## Step 4

### Connect the “Front” wire to one of the clips


90 degrees



- a) Force the orange lever up. **Yes, you'll feel like it's going to break!**




- b) Insert the wire you just removed.



- c) Snap the orange lever down. The wire should feel secure.

## Step 5

Connect your “Transformer” wire to the other clip



Note that your internal doorbell will no longer work. This is why we've included a Ring Chime.

## Step 6

Replace the cover on your internal doorbell.

Then go to the front of your home to install your Ring Doorbell Pro following the steps in the next manual.

