



ADJUSTABLE BED BASE


Table of Contents

- Unpacking Your Base ----- 1
- Attaching Legs To Base ----- 2
- Installing The Motors ----- 3
- Insert The Cords and Mattress Bar ----- 4
- Wireless Remote Instruction ----- 5
- Syncing Two Twin XL Base To make King ----- 6
- Troubleshooting ----- 7
- Warranty Information ----- 8-9



Unpacking Your Base

1. Open the carton box. Layout the bed frame and put two sections next to each other as shown.
2. Open all the parts boxes and cut the zip ties as shown.



Center Legs, 2PCS
Center Leg Bolts, 4PCS
Allen Key, 1PC

Corner Legs, 4PCS

Attaching Legs To Base

1. Locate the box containing the bed legs, tighten the two center legs with supplied Allen Key and center leg bolts.
2. Then tighten the 4 corner legs as shown.



Adjustable Leg Height

Three different leg heights to fit most bed frames.






Motor pins, 4PCS
Motor clips, 4PCS

Finished Motor Installation
Label "Facing Ground" On Top

Installing The Motors

1. Take motor pins and clips out of the motor bracket and assemble the motors as shown above.
2. Keep the label "Facing Ground" on top when the motors installed.



Motor pins, 4PCS
Motor clips, 4PCS

Finished Motor Installation
Label "Facing Ground" On Top

Insert the cords and retainer bar

1. Please insert the cords properly as shown:
 - ① Head Massage (Black plug) → Black image on control box
 - ② Foot massage (Blue plug) → Blue image on control box
 - ③ Head Motor (Black plug) → Black image on control box
 - ④ Foot Motor (Blue plug) → Blue image on control box
2. Insert the blue USB plug as shown, then insert the power cord and control box cord into the power adapter as shown.
3. Flip over the base, insert the mattress bar as shown.



Remote Instructions:

1. To sync the remote with the base, hold the red button on the control box in for 5 seconds. At the same time, hit any buttons on the remote, except "TV/PC, LOUNGE, FLAT, ZERO G" to turn it on. This will allow the remote to pair with the base.
2. "TV/PC, LOUNGE, FLAT, ZERO G" buttons must be programmed to your preset position. Use the Head/Foot Up and Down buttons to set your desired position.
3. Once the desired position is set, press and hold "ZERO G" button until the LCD screen image changes, approximately 2 seconds.
4. Press "ZERO G" button again. Please follow the same steps to set "TV/PC", "LOUNGE" buttons.

How to sync two Twin XL adjustable bases

1. Press + Hold the red button on the control box for 3 seconds from Base A. When it shows the red indicating light, press any buttons on the remote. If Base A works then move to the next step.
2. Using the same remote, Press + Hold the red button on the control box (on Base B) for 3 seconds. When it shows the red indicating light, press any button on the remote. If Base B works, it means the 2 beds will work together with one remote.



TROUBLESHOOTING

1. If there is no power, ensure all cables are properly connected, the plug is inserted securely in the outlet, and the outlet has power.
2. If the LED power indicator light on the remote control is not on, replace 1.5V 7 battery.
3. If the LED power indicator light on the transformer is not on, the transformer needs to be replaced.
4. If both LED power indicator lights are on and there is no power, the motor needs to be replaced.
5. Battery Backup: You must purchase two 9 volt batteries and install them in the AC/DC adapter on the Power Unit. This will function as a battery backup, which will allow the base to adjust to the flat position in case the power goes out. After installing the two 9 volt batteries, press the flat button to get the bed flat.

6. If the massage does not work,
 - ① Press+Hold red button on control box
 - ② Meanwhile, press head massage button on remote
 - ③ If the massage works, then no problem with the massage
 - If the massage still does not work, the massage unit needs to be replaced:
 - ① Remove the massage sponge pad
 - ② Cut open the massage cover, exposing 4 silver screws.
 - ③ Loosen the 4 screws to remove the old massage unit and replace with the new massage unit. Then tighten 4 screws again
 - ④ Cover the sponge pad again

3-YEAR LIMITED WARRANTY INFORMATION

This warranty applies to new Classic Brands Adjustable Comfort Adjustable Base and is extended only to the consumer who makes the original purchase. This warranty is not transferable. The "adjustable base" does not include the mattress. "Warranty Commencement Date" means the date you purchased a new and unused Classic Brands Adjustable Comfort adjustable base. Classic Brands warrants this adjustable base to you on the terms and over the reducing periods of time set out below. All warranty claims require notice from you to be given to Classic Brands in the manner set out below, and to be received by Classic Brands inside the applicable warranty time period.

LIMITED WARRANTIES

Limited Warranties are non-transferable. The following Limited Warranties are given to the original retail purchaser of the following Classic Brands Adjustable Comfort Adjustable Base Product.

YEAR 1 THROUGH 3 - FULL COVERAGE OF PARTS

Your Classic Brands Adjustable Comfort Adjustable Base is warranted against defects in the workmanship or materials for a period of one (1-3) year from the warranty commencement date. Electronics, electrical components, drive motors and massage motors are included. Upon notice during the first year from the warranty commencement date, Classic Brands will send replacement parts (at no cost to the purchaser) for any defective part to the purchaser. This three (3) year warranty shall not apply if purchaser does not return any and all defective parts to Classic Brands within 15 days of purchaser's receipt of replacement part. Purchaser shall bear all service, transportation, labor, and shipping costs related to the delivery and/or replacement of the defective part.

WARRANTY LIMITATIONS EXCLUSIONS:

This warranty does not apply: (a) to any damage caused by You; (b) if there has been any repair or replacement of adjustable base parts by an unauthorized person; (c) if the adjustable base has been mishandled (whether in transit or by other means), subjected to physical or electrical abuse or misuse, or otherwise operated in any manner inconsistent with the operation and maintenance procedures outlined in the Owner's Manual and this warranty; (d) to damage to mattresses, fabric, cables, electrical; (e) if there has been any modification of the adjustable base without prior written consent by Classic Brands or (f) to costs for unnecessary service calls, including costs for in-home service calls solely for the purpose of educating You about the adjustable base or finding a satisfactory power connection. Any repairs to or replacement to Your adjustable base or its components under the terms of this limited warranty does not extend the applicable warranty from the Warranty Commencement Date. The decision to repair or to replace defective parts under this warranty shall be made, or cause to be made, by Classic Brands at its option and in its sole discretion. Repair or replacement shall be the sole remedy of the Purchaser. There shall be no liability on the part of Classic Brands for any special, indirect, incidental, or consequential damages or for any other damage, claim, or loss not expressly covered by the terms of this warranty. This limited warranty does not include reimbursement for inconvenience, removal, installation, setup time, loss of use, shipping, or any other costs or expenses. Additionally, this warranty applies under conditions of normal household uses and does not apply to defects resulting from negligence, misuse, accidental or commercial rental usage. All implied warranties, including implied warranties of merchantability and fitness for a particular purpose, are limited to the duration of the express warranties on this product. The warranties and remedies set forth in this limited warranty are exclusive and in lieu of all others, oral or written, express or implied, in no event will Classic Brands be liable to you for any damages, including incidental or consequential damages, arising out of the inability to use this product. Some States do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state. All warranties are applicable to the original consumer purchaser only, and do not apply to any commercial and/or non-residential users.

Brands for any special, indirect, incidental, or consequential damages or for any other damage, claim, or loss not expressly covered by the terms of this warranty. This limited warranty does not include reimbursement for inconvenience, removal, installation, setup time, loss of use, shipping, or any other costs or expenses. Additionally, this warranty applies under conditions of normal household uses and does not apply to defects resulting from negligence, misuse, accidental or commercial rental usage. All implied warranties, including implied warranties of merchantability and fitness for a particular purpose, are limited to the duration of the express warranties on this product. The warranties and remedies set forth in this limited warranty are exclusive and in lieu of all others, oral or written, express or implied, in no event will Classic Brands be liable to you for any damages, including incidental or consequential damages, arising out of the inability to use this product. Some States do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from state to state. All warranties are applicable to the original consumer purchaser only, and do not apply to any commercial and/or non-residential users.

