

BLACK

Configure NEO on your smartphone

- 1**

Scan the QR code to download NEO app at App Store or Google Play. You can also search keyword "ANKUOO" at App Store or Google Play to download NEO app.

Free NEO app from App Store
- 2**

Connect your smart device to local 2.4G Wi-Fi network and launch NEO app. Find "add new device" in the menu.
- 3**

Press ON/OFF button on NEO Switch for 5 seconds until Wi-Fi indicator starts to flash quickly.

Make sure your smart device and NEO Switch are in the same 2.4G Wi-Fi network. The process takes about 15-30 seconds, depending on your network condition and the length of Wi-Fi password.
- 4**

When configuration is done, the NEO Switch will be shown on the NEO app. You can change the ON/OFF state at the homepage.
- 5**

Select "Invited" to stop other people adding NEO Switch to their own NEO app.

Click the star to enter desired setting page.
- 6**

NEO comes with three timer setting modes. You can set them at anywhere with an internet connection using your NEO app.

 - Random Timer**: You need always change the NEO Switch to the time you set.
 - Set Back Timer**: You can set the time to which the light will turn on after a certain period. When the set time is achieved, the other two timers will be disabled.

NEO
Wi-Fi Wall Switch

- Remote Control**: You control your electrical appliances with ease.
- Automation Timer**: You can change your electrical appliances.
- Set Back Timer**: You can set the time and control the time when the light will turn on.
- Random Timer**: You can set the time when the light will turn on.

ANKUOO
SMARTER SOLUTION FOR LIFE

THINGS TO KNOW BEFORE USING NEO

- Make sure your router is configured to 2.4G, and your smartphone is connected to the 2.4G network.
- Make sure the electronic device shown on your iOS/Android NEO app is the one plugged into the NEO Switch.
- Make sure you have a strong Wi-Fi signal at the NEO Switch.
- The signs and all operations of NEO Wi-Fi Switch are only possible via a Wi-Fi network connected to the internet.
- NEO Switch needs to be on again when the SSID or password is changed.
- No need to setup the NEO Switch again when you turn it off or unplug it from one socket and plug it into another socket.
- NEO Switch will appear on all iOS/Android devices with NEO app installed and in the same Wi-Fi network.
- The clock of NEO Switch is synchronized to the cloud server; not your local iOS/Android device. Set 2 minutes delay is perfectly normal.
- NEO Switch has to be synchronized again after the firmware is updated (successfully or not).

Before you install

- 1 Replaces single-pole switch only**

NEO Wi-Fi Light Switch replaces single-pole switch only, not compatible with 3-way (three location control) switches.
- 2 Wi-Fi Signal Verification**

Take your smartphone to the light switch you are replacing. Please make sure you have at least 50% Wi-Fi signal.
- 3 Safe Installation**

Warning! This is an electrical work hazard! Incorrect installation could be dangerous or fatal. Multiple warnings may need to be developed for safe installation. Please call a professional electrician if you are unfamiliar or uncomfortable with electrical work.

Installation Guide

Turn off the power
Turn off power at circuit breaker for the switch you are replacing. Flip your light switch a few times to ensure the power is off.

Remove the Old Switch
Document the wires and remove your old switch. Take a picture for later reference (optional).

Install the NEO Wi-Fi Wall Switch

Check Wire Connection
Make sure all the connections are correct and wire nuts are secured.

Screw in NEO
Screw in NEO Light Switch and attach faceplate.

Turn power back on

NEED MORE HELP?
Contact your distributor, please visit our website for answers and troubleshooting tips.

ANKUOO
SMARTER SOLUTION FOR LIFE

© 2014 Ankuoo (Shenzhen) Ankuoo Technology. All rights reserved. NEO0504272