

i-FlashDevice

User Manual


- App Overview
- Edit Shortcuts
- Apply 3rd Party's Player
- One Touch On-the-go
- File Management
- Data Security
- App On-lock




V1.1

App Overview – Main Interface

i-FlashDevice App Interface



Settings



Remark:


* Gesture Control and Touch ID Access are off under initial setting.

App Overview – Sub-interface

User Interface






Editing Interface






Edit Shortcuts

1. Creat 'Folder' Shortcut





Edit Shortcuts

2. Creat 'File' Shortcut




Edit Shortcuts

3. Delete Shortcut --- Touch & Hold ICONS, then delete



Apply 3rd Party's Player


Remark: If it is not yet installed, Please search and install it through App Store.




File Management – Data Backup

Backup photos/videos/files from your iOS device to the i-FlashDevice


1. Launch the i-FlashDevice App, and choose "Album".




2. Tap on the "Camera Roll" or other specified.




3. Press "Edit" to enter the editing mode.




4. Select the photo/video/file you want to back up, then tap "Done".



5. Choose "Device Storage" and decide which file folder to store.




6. Click "Copy to" as manual confirmation to transfer the data.




File Management

Import external photos to your iPhone/iPad Album via i-FlashDevice


1. Launch the i-FlashDevice App, and choose "Album".




2. Find the right file folder to store the external photos and tab "Import".




3. Tab the button "Device Storage" and choose the folder your target photos lie in.




4. Tab "Edit" in the right upper corner to enter Editing mode.



5. Tick the photos to be imported into iPhone/iPad, and finally press "Import".




6. Upon importing finished, you can view the moved photos in your iPhone/iPad Album..




One Touch On-the-go

Using i-FlashDevice to take Photo and Video screen shot


1. Launch the i-FlashDevice App, and choose "Camera".




2. Put focus on the people or thing that you want to take photo, and confirm how to dispose the picture via tapping the "Retake" or "Use Photo".



1. Launch the i-FlashDevice App, and choose "Video".




2. Put focus on the people or thing that you want to take video, and confirm how to dispose the video via tapping the "Retake" or "Use Video".




One Touch On-the-go

Using i-FlashDevice to take Sound and Contact List screen shot


1. Launch the i-FlashDevice App, and choose "Recorder".




2. Press the RED button when starting the record, and a 2nd press when completed. You can press "Play" button to check first before tapping the icon of "Trash" or "Saved".



1. Launch the i-FlashDevice App, and choose "Backup".




2. Press the green button "Backups" to compress your contacts into a vcf file. Connect to the new iPhone and tab the pink button "Recover" choosing the latest record.




Data Security

Add Password to specified files kept in high confidence and privacy


1. Find the specified confidential file and simply tab the "i" icon.



2. Input the Password and it starts compressing data into confidential document.




3. Only with a correct password can you open the lock file.



App On-lock

Protect in-App data with Gesture lock & Touch ID

1. Enter the i-FlashDevice App and go to "Setting".



2. Set you Gesture drawline and Touch ID.

