




**Sound Intone®**



**English**

[www.soundintone.com](http://www.soundintone.com)

**Sound Intone P6  
Wireless Bluetooth Headset**


## Introduction

Sound Intone P6 is a lightweight wireless headset that uses Bluetooth® version 4.0 technology.

Supporting with most Bluetooth enabled devices.


This product can be used as an audio accessory for devices.

## Headset



- ① Power switch/M mode switch button
- ② Next song/ Reduce volume
- ③ Previous song/ Increase volume
- ④ Play/Answer calls
- ⑤ TF slot

- ⑥ Charging jack( USB jack)
- ⑦ LED indicator light
- ⑧ Aux-in
- ⑨ Microphone



## Charging:


While charging, the LED indicator will show a solid red light  
When charging is complete, the LED indicator will turn off


**Low battery:**

A low battery will alert


If the battery is not charged, the headset will turn off


**Power on/power off**

Power on: Long press the  for more than 3 seconds, the headset will start up and enter “Bluetooth mode” automatically, LED indicator start blue and green light flash and finally turns to blue when connected.

Power off: Long press the  for more than 3 seconds, LED indicator will turn off.

**Button description:**

 ON/OFF/ Three kinds of modes (Bluetooth mode, Radio mode, TF mode) by single press.

 Play/pause/FM radio searching/ answer calls/hang up calls/make calls


 Short press reduce volume/long press for previous song or radio station

 Short press increase volume/long press for next song or radio station


**Button operation:**

1. Answer phone calls: short press  when calls' coming

2. Hang up a phone calls: short press  when calls' ends

3. Redial the last outgoing number: double-click 

4. Music play: short press  after connected with the smart device

5. Restart the music or FM: it will stop playing when calls coming. Short press  to restart after hang up the call.

## Introduction

### LED status

Charge status	LED indicator light steady red, when full charged, it turns off
Power on status	Blue LED indicator light turns on
Power off status	LED indicator light turns off
Pairing status	Green and blue LED indicator lights rapidly alternating flash
Connected status	Blue LED indicator light turns on
Using status	Bluetooth Mode, blue LED indicator light turns on
	Radio mode, green LED indicator light turns on
	Micro SD Card Mode, green LED indicator light flashes every 4 seconds
	AUX-in Mode, the headset automatically turns off, LED light turns off

### Specifications

Item	Description
Bluetooth Version:	V4.0
Support Profile:	AVRCP1.3, A2DP1.0, HFP1.5, HSP1.0
Working Distance Range:	10m
Frequency Range:	2,402GHz-2.480GHz
Battery Specifications:	3.7V, 300mAH, Built-in rechargeable lithium battery
Charging Voltage:	DC4.2-5.5V
Charging Time:	about 1.5 hours
Talking/Music time:	about 5 hours
Standby Time:	about 30 hours

## Pairing

Before using the headset for the first time, you must pair it with a Bluetooth-enabled device.

## Bluetooth Mode



### Pairing operation:

- a. For the first time pairing will boot into Bluetooth mode automatically, voice prompts Bluetooth mode, LED indicator light turns to green and blue light flashed, please open the smart device's Bluetooth searching function, and select the device "P6", no password is required, after successful pairing, voice prompts "Connected", LED indicator light turn to blue while working.
- b. Re-pairing: turn off the the attached smart device's Bluetooth function. If the headset can't search and pair with the last connected smart device within 3 seconds, it will automatically re-enter the pairing mode.
- c. Follow-up pairing: automatically pair the last connected device in 3 seconds after boot.

### Micro SD Card Playback Mode

- a. When the slot is empty, inserted the Micro SD Card, LED indicator light turns to green, voice prompts "Music". Then it plays media automatically, LED indicator light turns to green flashing every 4 seconds.
- b. When the Micro SD Card is inside, switch to Micro SD Mode through Mode

### FM Radio Mode

- a. When the headset is on, switch to FM Radio mode through Mode, voice prompts "Radio Mode", LED indicator light turns to green.
- b. Usage tips: long press  for 2 seconds to search and save stations automatically (it can be abort with another short press while searching). Once enter FM Radio mode again, it will play the first saved radio station automatically. If you want to re-scan, long press  for 2 seconds again in the Radio mode.

### AUX-in Mode

When the headset is on, inset the AUX-in cable. Then it plays smart device's media automatically.

#### Note:

- ① Maximum volume warning voice prompts "du du"
- ② Power saving function: if not successfully match for 5 minutes, the headset will automatic shutdown; insert the Aux-in cable will cut off the power supply to save power.
- ③ Support with MP3,WAV,WMA,FLAC format playback.
- ④ Battery indication on IOS.
- ⑤ Micro USB as common use charging port.

**CAUTION**

- TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVER. THERE ARE NO SERVICEABLE PARTS INSIDE.
- TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE.

**Safety and Handling Information**

1. For maximum product life, do not drop, throw, or crush the headset. Do not expose it to humidity, dust, or operating temperatures outside 32°F to 113°F (0°C to 45°C). Avoid charging it in temperatures above 113°F (45°C).
2. Avoiding hearing damage. Permanent hearing loss may occur if you use your headset at a high volume. Set the volume to a safe level. Over time you can become accustomed to a higher volume that may sound normal but can be damaging to your hearing. If you experience ringing in your ear or muffled speech, stop listening and have your hearing checked. The louder the volume, the less time is required before your hearing could be affected.

**Hearing experts suggest that to protect your hearing:**

- Limit the amount of time you use the headset at high volume.
- Avoid turning up the volume to block out noisy surroundings.
- Turn the volume down if you can't hear people speaking near you.

**Using headsets safely**

Use of headsets to listen to music while operating a vehicle is not recommended and is illegal in some areas. Be careful and attentive whilst driving. Stop using this device if you find it disruptive or distracting whilst operating any type of vehicle or performing any other activity that requires your full attention.

## Warning

### **DANGER:**

To reduce the risk of electric shock, burns, fire or injury:

1. Do not use while bathing or in a shower;
2. Do not place or store unit where it can fall or be pulled into a tub or sink;
3. Do not place in, drop or submerge in water or other liquid;
4. Do not place reach for a unit that has fallen into water. Unplug it immediately;
5. Care should be taken so that objects do not fall and liquids are not spilled onto the unit.

### **Warning**

1. As the headphones are on ear design, sounds go out through the headphones. Remember not to disturb those close to you;
2. This package contains small parts that may be hazardous. Close supervision is necessary when this appliance/product is used by or near children or mentally disabled individuals.
3. Do not apart the headphone randomly! None of the components can be replaced or repaired by users. Only authorized seller or service centers may open the product. If any parts of your product require replacement for any reason, including normal wear and tear or breakage, please contact seller for warranty;
4. If the product overheats, if the product has been dropped or damaged, if the product has a damaged cord or plug, or if the product has been dropped in a liquid, discontinue use and contact seller directly.
5. Use this unit only for its intended use as describe in this manual
6. Unplug this unit during lighting storms or when unused for long period of time

7. Never drop or insert an object into any opening.
8. Protect the power cord from being walked on or pinched, particularly at plug outlets, convenience receptacles and the point where it exits the unit.
9. Do not allow cord to touch hot surfaces. Wrap cord loosely around the unit when storing.
10. The unit should be situated away from direct sunlight or heat sources such as radiators, electric heaters, hear registers, stoves, or other units(including amplifiers) that produce heat. Avoid placing on top of stereo equipment that radiates heat.
11. Never block the air opening of the unit with materials such as clothing, plastic bags or papers, or place it on a soft surface such as a bed or couch, where the air opening may be blocked.
12. Do not overload the electrical outlet. Use only the power source as indicated.

<b>Troubleshooting</b>	
Issue	Resolution
<p>Unable to pair the P6 headphones with Bluetooth device</p>	<p>Check the Bluetooth is "visible" in your phone or computer, if pair timeout, pairing mode will exit, please re-enter pairing mode. If your phone application have some problems, please re-start the phone. If your device has problem, re-start or reset it.</p>
	<p>Restart the headphone</p>
	<p>Move back into the connection range and reconnect to your Bluetooth device.</p>
	<p>This headset will automatically syncs to the last device connect. If you need to reconnect to the first devices that was connected, reconnect it manually.Or delete the previous one, reconnect it.</p>
	<p>Pairing with a laptop,if there is no Bluetooth software on your laptop, please installed one on your computer first (can be download from the official website of your laptop brand)</p>
	<p>Devices like PS4,PS3 and TV etc. need additional Bluetooth transmitter to connect the headphone to your Bluetooth devices.</p>
<p>Unable to charge the P6 headphones</p>	<p>While charging, please make sure the plug is fully matches in the headphone jack</p>

Unable to charge the P6 headphones	Restart the headphone and try to charge it again.
	Change another USB charger to test if possible
	Reset the headphone( when the headphone is in pairing mode, plug the 3.5mm audio cable, then the headphone have been reset)
Unable to turn on the headset	Make sure your device is fully charged before using it for the first time. Your device can not be turned on if battery level is very low.
Unable to hear sounds when playback	Check the connection between your device with phone or computer, if the connection is not established, please reconnect again. And adjust the volume level to a suitable level
	Plug the audio cable to test whether the sound can be heard or not
Unable to voice dialing or redialing on my mobile phone.	Your mobile phone may not support this feature.
My Bluetooth headset is connected to a Bluetooth stereo enabled mobile phone, but music only plays on the mobile phone speaker.	Refer to the user manual of your mobile phone. Select to listen to music through the headset.
The audio quality is poor and crackling noise can be heard.	The Bluetooth device is out of range. Reduce the distance between your headset and Bluetooth device, or remove obstacles between them. Plug the 3.5mm audio cable in it to test whether the headset can be heard clear in wired use.



**Sound Intone®**

## **Sound Intone P6 Wireless Bluetooth Headset**

### **Service and Support**

If your device is not performing as it should, please contact with your seller directly. **E-mail: [service@soundintone.com](mailto:service@soundintone.com)**

### **Protection to Fix Card**

Warranty Period:  
12 months from the date you purchase.

Free Service:  
During the warranty period, if there is any breakdown which caused by the product's own quality, please contact your dealer with purchasing invoice to enjoy free maintenance.

Free maintain won't be given under the following circumstance :

1. The damage caused by the dismantle movement of a non-our-company authorized maintainer.
2. The damage due to water or drop and machinery caused by human.
3. The breakdown and the damage caused by the force majeure.

**Customer service information: [service@soundintone.com](mailto:service@soundintone.com)**  
**Official website: [www.soundintone.com](http://www.soundintone.com)**