
07600C, 07600CZ, 07600D, 07600DZ, 27410A

Please read the following instructions carefully.
Keep this instruction manual and save for future reference.
For technical support, contact us at **1-401-671-6551**
or **www.summerinfant.com/contact**
Tools required: Phillips-head screwdriver,
measuring tape (not included), and wrench (included).
For use with children from 6 - 24 months.
Keep small parts away from children.
Adult assembly required.
Fits openings from 28.5 in. - 48 in. wide.



Text "Decorative" to 38344 for a demo & install video.
Have questions? We're here to help!
Please contact us at 401-671-6551 or www.summerinfant.com/contact.

Multi-Use Decorative Extra Tall Walk-Thru Gate

INSTRUCTION MANUAL

Thank you for purchasing the Multi-Use Decorative Extra Tall Walk-Thru Gate from Summer Infant. This gate allows you to create and maintain a secure environment for your child just about anywhere in your home. It has a hinged, swinging door that opens easily in either direction with one hand, as well as hold-open and auto-close features for added convenience.


⚠ WARNING

Children have died or been seriously injured when gates are not securely installed.

- **ALWAYS** install and use gate as directed using all required parts.
- Install according to manufacturer's instructions.
- STOP using when a child can climb over or dislodge the gate.
- Use only with the locking/latching mechanism securely engaged.
- To prevent falls, never use at top of stairs without wall mounting cups and door stopper.
- **NEVER** use a gate to keep child away from pool.
- **NEVER** leave child unattended.
- Always close and lock the gate behind you.
- This product will not necessarily prevent all accidents. Proper adult supervision is required at all times.
- Do not use if any components are missing or damaged.
- Adult assembly required. Exercise care when unpacking and assembling product.


⚠ CAUTION KEEP SMALL PARTS OUT OF CHILD'S REACH.

components:



- A Gate Door
- B Gate Frame
- C Long Extension Frame
- D Short Extension Frames (2)
- E Top Latch
- F Door Stop
- G Lower Latch
- H Extension Pins (6)
- I Tension Bolts with Tension Nuts (4)
- J Adhesive Mounting Pads (4)
- K Wall Cups (4)
- L Wall Anchors (4)
- M Screws (4)
- N Wrench

hardware:




gate configurations (choose which best fits your scenario):

Measure the width of the opening where you intend to install the gate.


- Refer to the following illustrations to determine the correct installation configuration.
- Baseboard molding may change which configuration is appropriate.

⚠ WARNING

NEVER install three extension frames on the same side of the gate.




(28.5 in.- 32 in.) without extension frames




(32.5 in.- 36 in.) with one short extension frame


- If mounting the gate at the top of the stairs, begin with installation step #1.
- If mounting the gate in openings away from stairs, begin with installation step #4.




(36.5 in.- 40 in.) with one long extension frame



(40.5 in.- 44 in.) with one short and the long extension frames



(44.5 in.- 48 in.) with both short and the long extension frames



IMPORTANT:

Gate includes a door stop (part F in components) which prevents the gate from swinging open in one direction.

- When installing the gate at the top of stairs, be sure the door stop is on the stairway side of the gate so the door cannot open over the stairs.
- While the door stop comes fully assembled on gate, it can be removed and installed on either side of gate frame.
- When gate is not used at top of stairs, door stop may be removed to allow gate door to open in either direction.


Note: This instruction book illustrates installation of gate configuration E.

- If choosing gate configuration A, skip step 4.
- If choosing gate configuration B, add only one short gate extension to either side of the gate frame in step 4.
- If choosing gate configuration C, add only the large gate extension to either side of the gate frame in step 4.
- If choosing gate configuration D, add only one short gate extension and the long extension to either side of the gate frame in step 4.

installation:


- If choosing gate configuration A, skip this step.
- If choosing gate configuration B, add only one short gate extension to either side of the gate frame.
- If choosing gate configuration C, add only the large gate extension to either side of the gate frame.
- If choosing gate configuration D, add only one short gate extension and the long extension to either side of the gate frame.





4





5


installation (continued):


Stand the gate in the center of the opening.

Make sure the bottom of the gate is completely flush to the floor.

Slide tension bolts out until they contact the door frame or the wall on both sides.

Make sure door stop is facing desired direction.
For top of stair use, door stop must be on stair side of gate.
Gate door must open away from stairs.







IMPORTANT


Check distances A &B.
The distance between the gate and the wall should never exceed 2.75"

6




Use the tension nuts to tighten both of the bottom tension bolts.







7

8



Use the tension nuts to tighten both of the top tension bolts.






STOP! wall cup/top of stairs installation:

⚠WARNING

For use at top of stairs, wall cup installation is MANDATORY.

Follow these wall cup installation instructions when using gate at **TOP OF STAIRS (MANDATORY),** or if using wall cups for a standard opening (optional).


If opting not to use wall cups for a standard opening, skip ahead to step 17.



⚠ IMPORTANT


At the top of the landing, position the gate a minimum of 3-6 inches (8-15cm) away from the top step.

9



10

wall cup/top of stairs installation (continued):





11

12

Note: If mounting directly into wood, skip this step.









wall cup/top of stairs installation (continued):


1st
Remove backing from one side of each adhesive mounting pad.




2nd
Attach one pad to the back of each wall cup.




3rd
Remove backing.






13

Align the wall cups so the center hole is placed directly over the wall anchor. Stick the wall cups to the wall.







Make sure all wall cups are facing up.

14

wall cup/top of stairs installation (continued):

Screw wall cups into wall.






15


16

IMPORTANT


NEVER open gate door over stairs.



Repeat "installation" steps on page 5. The 4 tension bolts will rest within each wall cup.




wall cup/top of stairs installation (continued):




FINISHED!


testing the installation:



1st

Close the gate. Make sure the upper and lower latches lock securely.






2nd

Push the gate and extension frames to check stability.

operation:


to unlock gate:

Slide locking tab back to release, lift gate door open.



hold-open feature:

To activate, open gate door at least 90° in either direction.



troubleshooting:


If the gate does not close properly:

1. Gate is not properly aligned in the door frame.

Solution: To adjust the gate's alignment, loosen all four tension bolts and reposition gate so that it matches the "correct" image. Re-tighten tension bolts.

2. Pressure of tension bolts needs to be adjusted.

Solution: Loosen or tighten the upper tension bolts. Ensure the upper latch engages securely when the gate swings closed and that it can be released properly when the sliding lock tab is pushed back.



maintenance:

- Regularly check tension bolts to make sure the gate is securely in place.
- Do not use the gate if any components are damaged or missing.
- Surface-clean with a damp cloth or sponge, using mild detergent and warm water.
- To order a hardware replacement kit (item #07600-10), contact our Consumer Relations Team online or by phone at 1-401-671-6551.

We're here to help!
If you have any questions or need assistance, contact our Consumer Relations Team at **1-401-671-6551** or **www.summerinfant.com/contact**

summer®

Summer Infant (USA), Inc.
1275 Park East Drive
Woonsocket, RI 02895 USA
1-401-671-6551
© 2019 Summer Infant (USA), Inc.

Colors and styles may vary.
MADE IN CHINA.
01/28/19