

Siphon Pump Instructions

1 Be sure the plastic tip on the end of each clear tube is inserted into the black siphon bulb. (Already inserted in package)

2 Place long clear tube into the liquid to be siphoned. Make sure the liquid to be siphoned is **above** the container receiving the liquid.



3 Place your finger over the end of the tube which will be receiving the liquid. **Squeeze the siphon bulb 2 to 3 times** to begin the flow of the liquid. **Remove your finger** and allow the liquid to flow into the empty container.

NOTE. If you are pumping gas, make sure the hose is pushed deep into the tank. Before you store the siphon pump, be sure all liquid is drained out of bulb and hose. Store in a cool place.