

Quick Start Guide

1. TURNING ON YOUR CAMERA

To turn on your Polaroid POP, press and hold the RED BUTTON. If the camera does not turn on within a few seconds, charge the camera using the provided USB cable and a high-quality, brand name charger rated at 5V/2A max. If you continue to experience issues, please reset the camera (insert a pin into the reset button located next to SD slot) and update the [firmware](#).

2. PAIRING YOUR CAMERA WITH YOUR MOBILE DEVICE

iOS and Android™ issues can cause problems for non-internet Wi-Fi® devices. Disable the auto-connect setting on all saved networks that are within range of the Polaroid POP.

- iOS (Version 11 and higher): 1) Tap Settings > Wi-Fi®. 2) Tap next to the network name. 3) Disable Auto-Join.
- Android (Version 7 and higher): 1) Tap Settings > Wi-Fi®. 2) Tap Advance > Manage Networks. 3) Tap Network Name. 4) Disable Auto Reconnect.

3. UPDATING YOUR FIRMWARE

We're continually improving our firmware to give you the best performance and most enjoyment from your camera, so please check for firmware updates frequently!

Press [here](#) to get the latest firmware. Download to a microSD™ card or use our app.

4. PRINTING FROM THE POLAROID POP APP

Make sure the auto-reconnect setting has been removed from all nearby Wi-Fi® networks. Click on the app store icon and check that the Polaroid POP app has been downloaded. If the app freezes or otherwise fails on your iOS device, tap the Home button twice and slide the Polaroid POP app off the screen to close it. For Android™ devices, press the split view icon on the bottom left and slide the Polaroid POP app off the screen. Then restart the app and try again.