

Activity Table Standard and Preschool Height



WARNING:


Adult Assembly Required.

Two adults recommended.

- Contains small parts, sharp points and edges.
- Do not stand, sit, kneel, climb, lean or pull on unit for support.
- Never leave children unattended.
- Do not place unit near high heat or moisture.
- Adult supervision recommended.


NOTE:

A Phillips Screwdriver and a Rubber Mallet may be needed for assembly (not included)




Parts List


BEFORE ASSEMBLING, MAKE SURE THERE ARE NO MISSING PARTS.



B Upper Leg Support (4)



C Lower Leg Extension (4)



D Phillips Screws (13)



E Hex Screws (8)



F Hex Tool



Attach Legs to Table Top

1. Place Table Top (A) face down, on a carpet or protected surface to prevent scratches.
2. Slide Receiver Plate of Top Leg (B) under the edge of one of the corner brackets.
3. Tap the Top Leg (B) into place with a rubber mallet until the pilot hole is visible through the center hole in the leg plate. If needed, loosen the screws to allow more clearance.
4. Using the Phillips Head Screws (D) (3 per Leg), attach the leg using a Phillips Screwdriver. Do not use power tools as the screw holes can be stripped from over tightening.
5. Repeat steps 2 through 4 for the other 3 legs. Make sure all screws are fully tightened.





Table Leg Height Adjustment

Insert Lower Leg (C) into Upper Leg (B) and line up holes at desired height as shown below. Fasten each leg with 2 Hex Head Screws (E) using Allen Wrench (F).



Sprogs Size Leg

Norwood Size Leg

Care and Cleaning

Clean table with a damp cloth or sponge using warm water and mild soap. Wipe dry.

Do not place near heat, moisture or vaporizer which may cause table to warp and peel.

Check for loose or worn parts periodically and tighten or replace as necessary.