

Lenovo YOGA Mouse

Quick Start Guide

The Lenovo logo is positioned in the bottom right corner of the page. It consists of the word "Lenovo" in a white, sans-serif font, oriented vertically within a solid black rectangular background. A small trademark symbol (TM) is located at the top right of the word.

Lenovo™


Contents

Parts and locations	1
Umístění součástí.....	7
Pièces et emplacements.....	13
Τμήματα και θέσεις εξαρτημάτων.....	19
Komponenten und deren Lage	25
A fejhallgató részei	31
Parti e ubicazioni.....	37
部品および位置	43
Części i rozmieszczenie.....	49
Componente și locații	55
Расположение компонентов	61
部件和位置	67
Piezas y ubicaciones	72
零件和位置	78
Parçalar ve yerleri	83
Peças e locais.....	89

In the box



Parts and locations



1 Middle key	2 Touch bar*
3 Right key	4 Indicator*
5 Power button*	6 USB charging connector
7 Wireless mode switch	8 Windows® key
9 Left key	10 Compartment cover

*Touch bar:

Function: vertical scrolling

How to use: swipe up and down

***Indicator:**


Indicator status	Mouse status
Blinking white	Bluetooth pairing
Blinking orange	Battery low
Solid orange	Charging
Solid white	Fully charged


***Power button:**

- To turn on the mouse, press and hold the power button for two seconds until the indicator turns white for three seconds.
- To turn off the mouse, press and hold the power button for two seconds until the indicator turns off.

Connecting the mouse to a computer

Connect through the USB receiver




Ensure that the wireless mode switch is in the position . Then, the computer automatically identifies the mouse.



Connect through the Bluetooth feature

Computer requirements:

- Bluetooth 4.0 or later
- Microsoft® Windows 8 operating system or later



Do the following to the mouse:

Hold the wireless mode switch in the position  for three seconds until the indicator flashes white. Release the wireless mode switch and it automatically returns to the position .

Do the following to the computer:

1. Select **Lenovo YOGA Mouse** from the Bluetooth device list.
The computer starts pairing with the mouse.
2. After the Bluetooth connection is established, disable **Allow the computer to turn off this device to save power**.

For more information, refer to the Windows help information system.

Using the mouse


Switch between the mouse mode and the presenter mode

Note: Ensure that the wireless connection is established.

- **Mouse mode**

Function: mouse


How to enter: rotate clockwise from the presenter mode




- **Presenter mode**











Function: media controller or presenter

How to enter: rotate counterclockwise from the mouse mode



The media controls or presenter controls are lit.



Media controls	Presenter controls
 Volume down	 Presenting from the first slide
 Volume up	 Presenting from the current slide
 Play/Pause	 Black the screen/Back to presentation
 Previous track	 Previous slide
 Next track	 Next slide

Note: To switch between the media controller and presenter, press the middle key.

The mouse enters hibernation mode if it is not used for over three minutes as a media controller or over 10 minutes as a presenter. To wake up the mouse, press the middle key or the Windows key.

Troubleshooting

Problem: The mouse is not working.

Solution:

- Ensure that the wireless mode switch is in the correct position.
- Ensure that the mouse is fully charged and turned on.
- Use the mouse on a different surface.
- For connection through the Universal Serial Bus (USB) receiver:
 - Ensure that the USB receiver is securely connected.
 - Connect the USB receiver to another USB connector.

- For connection through the Bluetooth 4.0 feature:
 - Ensure that the mouse has been disconnected from other devices before pairing.
 - If the Bluetooth connection is lost, re-pair the mouse first. If the problem persists, try restarting the computer and then re-pairing.
- In the presenter mode, if the controls are not lit, ensure that the mouse is connected to the computer.
- If the black-screen control is not working, ensure that the current input language supports keyboard shortcuts by your Microsoft PowerPoint® program.
- If the indicator does not respond anyway, reset the mouse. To reset the mouse, press and hold the power button, charge the mouse using the USB charging cable, and then release the power button.
- If the battery power consumes fast, always turn off the mouse to save power when you finish using the mouse.