


GunVault[®]
THE ORIGINAL. SINCE 1990

SAFE
QUICK
STRONG
SMART[®]



Please visit GunVault.com for Replacement Promise details*

Safe To Armed In Seconds[™]

SpeedVault[®]

SV500
SVB500

Leaders in Responsible Firearm Storage

Since 1990, GunVault has been an industry leader and innovator of quick access personal safes. We pride ourselves on our commitment to manufacture a responsible firearm storage solution with the highest in quality and patented design. At GunVault we stand behind our products. We understand that in a time of crisis you rely on the security and protection GunVault provides.

Thank you for your trust and welcome to the GunVault family.



A SAFER WAY OF LIVING®

Index

»» Quick Start Guide	02
»» Product Features for Digital Unit	04
»» Programming Digital Keypad	04
»» Installing Digital SpeedVault	05
»» Safety Features for Digital Unit	05
• Tamper Detect Feature	
• Low Battery Warning Indicator	
• Security Sleep Mode Feature	
• Mute Button Feature	
»» Product Features for Biometric Unit	07
»» Programming Biometric Swipe Scanner	07
»» Programming Additional Users	08
»» Opening Unit Using Biometric Swipe Scanner	08
»» Installing Biometric SpeedVault	08
»» Deleting Users/ Resetting Biometric Unit	08
»» Safe Features for Biometric Unit	09
• Low Battery Warning Indicator	
• Mute Button Feature	
»» Warnings	10
»» GunVault's Exclusive 5 year Warranty	11
»» Warranty Registration	12

Quick Start Guide

Need a quick start solution so you can begin using your safe? We've got you covered. Our easy quick start guide will help you setup your safe in no time.

▶▶▶ Quick Battery Install

Unit includes backup keys.

Step 1: Open the unit with the backup keys provided.

Step 2: Locate the battery compartment on the interior roof of safe. Open and insert the recommended 9V alkaline battery.

Step 3: When the battery is connected you will hear a single beep, signaling that unit is powered.

***The lock manufacturer highly recommends the use of either a Duracell or Energizer 9V alkaline battery with an expiration date of 5 years into the future.**

▶▶▶ Quick Programming For Administrator Fingerprint (For Biometric Unit Only)

New units are set in DEMO mode, meaning the unit can open without a fingerprint by pressing the Start button. The first two fingerprints enrolled are the administrators, they allow the enrollment of additional users.

Step 1: Open the unit with the backup keys provided or by pressing the Start button located on the front keypad of the unit.

Step 2: Press and release the Learn/Mute button located on the interior roof of the unit. The unit will beep once and the indicator light will start flashing green. If the indicator light stops flashing after you have pressed the Learn/Mute button then you have been timed out and will need to press the button again.

Step 3: While the indicator is flashing green, place the tip of your finger at the top of the scanner and make a downward swiping motion taking one to two seconds per interval. The indicator light will flash green and you will hear a single beep. If the indicator light flashes red this indicates an unsuccessful swipe and you will need to repeat step 3 as needed.

Step 4: Keep swiping until you hear a double beep. A double beep indicates a successful enrollment of that fingerprint.

Step 5: Test the unit to ensure that your fingerprint was successfully programmed.

Step 6: To add a secondary user/fingerprint, repeat all steps. Your unit can store a maximum amount of 20 unique fingerprints.

▶▶▶ Quick Programming (Digital Unit Only)

Your access code can be a single press of one or more buttons at the same time. Your access code can be a minimum of 3 entries or maximum of 6 entries.

Step 1: Open the unit with the backup key provided or by using the factory default code. The factory default code is a single sequential press of 1-2-3-4.

Step 2: Press and hold the Learn button located on the interior roof of the unit. A beep will sound and the light will turn green and remain illuminated. This will indicate the enrollment procedure has been initiated.

Step 3: The indicator light will remain activated as you enter the new access code. The code can be a minimum of three entries or maximum of six entries.

Step 4: Press and hold the Learn button a second time until the indicator light beeps, turns red and remains illuminated. Then re-enter new access code.

Step 5: Press and hold the Learn button one last time until indicator light turns green and beeps six times. If the indicator light flashes red and beeps six times an error has occurred and you will need to repeat steps 2-5.

Step 6: Now your unit is programmed and ready to use.

▶▶▶ Quick Install for Biometric & Digital Units

The SpeedVault must be mounted at a 90° angle as the door is gravity operated. The unit can be mounted from the left, right or back side using the provided mounting holes.

Step 1: Secure the Mounting Bracket to desired location by fastening the wood screws through the wall mounting holes.

Step 2: After securing the Mounting Bracket, remove the two thumbscrews located on the bottom of the closed unit then proceed to remove the small bottom bracket.

Step 3: Once the small bottom bracket is removed use the backup keys provided to unlock the unit and remove drop down compartment from the shell of the unit.

Step 4: Align the shell of the unit to the mounting bracket and secure using the 3 woodcrews.

Step 5: Reinstall the removed drop down compartment to the shell and replace the small bottom bracket with the thumbscrews.

Step 6: Now you are ready to use your safe.

Safe To Armed In Seconds™



SCAN QR CODE TO VISIT OUR WEBSITE
FOR FAQ'S, VIDEO TUTORIALS, AND MORE.

Product Features

(DIGITAL SPEEDVAULT ONLY)

1. Indicator Light
2. Internal Courtesy Light (Inside the unit)
3. Learn Button (Inside the unit)
4. Mute Button (Inside the unit)
5. Battery Compartment (Inside the unit)
6. Bumper Bracket
7. Mounting Bracket
8. Digital Keypad
9. Keypoint
10. Wood Screws
11. Thumbscrew
12. Backup Keys



▶▶▶ Battery Installation (For Digital Unit Only)

When installing or replacing your battery, always hold the battery connecting cap while disconnecting or attaching. Do not pull on the power cables, this could cause the power supply to become disconnected from the lock. The lock manufacturer highly recommends the use of either a Duracell or Energizer 9V alkaline battery with an expiration date of 5 years into the future.

Step 1: Open the unit with the backup keys provided, locate the battery compartment on the interior roof of the unit.

Step 2: Open the interior battery compartment cover and remove the battery plug-in cable.

Step 3: Insert the recommended 9V alkaline battery, following the Positive (+) and Negative (-) guides on the cable.

Step 4: When the battery is connected you will hear a single beep, signaling that unit is powered.

Step 5: Place the battery into the compartment and reinsert compartment cover.

▶▶▶ Programming Digital Keypad

Your access code can be a single press of one or more buttons at the same time. Your access code can be a minimum of 3 entries or maximum of 6 entries.

Step 1: Open the unit with the backup key provided or by using the factory default code. The factory default code is a single sequential press of 1-2-3-4.

Step 2: Locate the Learn button next to the battery compartment on the interior roof of the unit.

Step 3: Press and hold the Learn button. A beep will sound and the light will turn green and remain illuminated. This will indicate that the enrollment procedure has been initiated.

Step 4: The indicator light will remain activated as you enter the new access code. The code can be a minimum of three entries or maximum of six entries.

Step 5: Press and hold the Learn button a second time until the indicator light beeps, turns solid red and remains illuminated, then release.

Step 6: Enter your new access code a second time. During this step the red indicator light will remain illuminated.

Step 7: Press and hold the Learn button a third time. The indicator light will flash green and beep six times, this will confirm that the new code has been accepted. If the indicator light illuminates in red and beeps six times, an error has occurred and you will need to repeat steps 3-7.

Step 8: Test your combination to confirm your new access code.

Step 9: Now you are ready to use your safe.

»» Resetting Passcode Digital Keypad

Step 1: Open the unit by using either your backup keys or current access code and locate the Learn button, on the interior roof of the unit.

Step 2: Use steps (3-7) in the "Programming Digital Keypad" section to change your current combination.

Step 3: Now you have successfully reprogrammed your safe.

»» Installing Digital SpeedVault

SpeedVault must be mounted at a 90° angle as the door is gravity operated. The unit can be mounted from the left, right or back side using the provided mounting holes.

Step 1: Select a location to mount the unit.

Step 2: Secure the Mounting Bracket to desired location by fastening the wood screws through the wall mounting holes.

Step 3: After securing the Mounting Bracket, remove the two thumbscrews located on the bottom of the closed unit.

Step 4: Unlock the unit with the backup key and remove the drop down compartment from the shell of the unit.

Step 5: Secure and fasten the shell of the unit to the Mounting Bracket by using the 3 woodscrews provided.

Step 6: Reinstall the removed drop down compartment to the shell and restore the small bottom bracket with the thumbscrews.

Step 7: Your unit is now installed.

Safety Feature Section Digital Unit Only

»» Tamper Detect Feature

Entering an invalid access codes triggers the Tamper Detect feature.

Step 1: Press and hold down buttons '2' and '3' for five seconds to initiate the Tamper Detect indicator.

Step 2: If tampering has been detected, the indicator light will remain red until buttons '2' and '3' are released.

Step 3: If tampering was not detected, the indicator light will remain green until buttons '2' and '3' are released.

»» Low Battery Warning Indicator

Step 1: When you enter the correct combination and the battery is low, the indicator light will flash red and beep six times. Depending on the low battery level, the unit may sound when releasing the lock. If the battery level is too low, the indicator light will start to flash red and beep continuously until the battery is removed from the unit. If the battery in the unit is completely depleted, you will hear only a light humming sound.

Step 2: Replace battery by using steps in section labeled "Battery Installation".

***You must open your unit in order for the low battery indicator to alert you.**

»» Security Sleep Mode Feature

Step 1: After six incorrect entries the Security Sleep Mode feature will be triggered and will lockout any new keypad entries for two minutes. When Security Sleep Mode is active and a button is pressed the indicator will flash red and beep three times.

Step 2: To verify if the "Security Sleep Mode" is now deactivated, after (2) two minutes have passed test your unit by slowly typing in your combination. If the indicator light flashes green your combination has been accepted and the unit will open. If the indicator flashes red your combination is incorrect and you will need to try again. If you have forgotten or lost your combination please follow the instructions in section labeled "Programming Digital Keypad", your backup key will be required.

»» Mute Button Feature

This feature will mute or unmute the audio in your unit.

Step 1: Open the unit and locate the Mute button on the interior roof of the unit.

Step 2: Press and hold the Mute button for three seconds. While holding the mute button, the indicator light will remain solid red. When the indicator light flashes green and beeps 3 times this will indicate a successful activation.

Step 3: Now you have successfully activated/deactivated the mute feature.

»» Internal Courtesy Light

• The interior courtesy light feature becomes activated for five seconds after every time the safe door opens. This feature allows you to have a clear view of the interior and all the safe contents.

»» Installing Bumper Bracket

Step 1: Locate the bumper bracket installation holes on the bottom of the unit.

Step 2: Once located, align the Bumper Bracket with the installation holes.

Step 3: Proceed to securely fasten the Bumper Bracket to the unit with the provided screws and screw driver.

Step 4: You have successfully installed the Bumper Bracket.



Product Features

(BIOMETRIC UNIT ONLY)



1. Indicator Light
2. Start Button
3. Internal Courtesy Light
(Inside the unit)
4. Learn/Mute Button
(Inside the unit)
5. Delete Button
(Inside the unit)
6. Battery Compartment
7. Bumper Bracket
8. Mounting Bracket
9. Swipe Scanner
10. Keypoint
11. Wood Screws
12. Thumbscrew
13. Backup Keys



▶▶▶ Battery Installation (For Biometric Unit Only)

When installing or replacing your battery, always hold the battery connecting cap while disconnecting or attaching. Do not pull on the power cables, this could cause the power supply to become disconnected from the lock.

Step 1: Open the unit with the backup keys provided and locate the battery compartment on the interior roof of the unit.

Step 2: Open the interior battery compartment cover and remove the battery plug-in cable.

Step 3: Insert the recommended 9V alkaline battery, following the Positive (+) and Negative (-) guides on the cable.

Step 4: When the battery is connected you will hear a single beep, signaling that the unit is powered.

Step 5: Place the battery into compartment and reinsert compartment cover.

The lock manufacturer highly recommends the use of either a Duracell or Energizer 9V alkaline battery with an expiration date of 5 years into the future.

▶▶▶ Programming For Administrator Fingerprint (For Biometric Unit Only)

New units are set in DEMO mode, meaning the unit can be opened without a fingerprint by pressing the Start button. The first two fingerprints enrolled are the administrators, they allow the enrollment of additional users.

Step 1: Open the unit with the backup key provided or by pressing the Start button located on the keypad of the unit.

Step 2: Locate the "Learn/Mute" button next to the battery compartment on the interior roof of the unit.

Step 3: To enroll your first and second administrator fingerprint, press and release the Learn/Mute button. The unit will beep once and the indicator light will begin to flash green indicating that your unit is now in learn mode. If the indicator light stops flashing after you have pressed the Learn/Mute button then you have been timed out and will need to press the button again.

Step 4: While the indicator light is flashing green, place the tip of your finger at the top of the reader guide, then swipe your finger in a downward swiping motion taking one to two seconds per interval. The indicator light will flash green and you will hear a single beep. If the indicator light flashes red this indicates an unsuccessful swipe and you will need to repeat this step as needed. If the green indicator light stops flashing you will need to repeat step three.

Step 5: Keep swiping until you hear a double beep. A double beep indicates a successful enrollment of that fingerprint. It may take three or more swipes until the fingerprint is enrolled.

Step 6: Test your unit to confirm that your fingerprint was accepted.

Step 7: To add a secondary user/fingerprint repeat steps 2 – 5.

Step 8: Now you are ready to use your safe.

»» Programming Additional Users

Leave the unit door open while you program your safe. An administrator fingerprint will be required for enrolling any secondary fingerprints/users.

Step 1: After enrolling the first two administrator fingerprints, open the unit by using your backup key or biometric scanner.

Step 2: Press and release the Learn/ Mute button on the interior roof of the unit. The unit will beep once and the indicator light will begin to flash green. The secondary user enrollment procedure has begun.

Step 3: While indicator light is flashing green, swipe the administrator fingerprint and you will hear two beeps indicating the unit is ready for additional fingerprints to be enrolled. The indicator light will continue to flash green during steps 2 to 5, if flashing stops before completing these steps you will need to repeat from the beginning.

Step 4: While the indicator light is flashing green, place the tip of the new fingerprint at the top of the scanner and make a downward swiping motion taking one to two seconds per intervals, until the entire finger has crossed the scanner. A single beep indicates a successful swipe. If indicator light flashes red your swipe was unsuccessful and you will need to swipe again.

Step 5: Keep swiping until you hear a double beep. A double beep indicates a successful enrollment of that fingerprint. It may take three or more swipes until the fingerprint is enrolled.

Step 6: To enroll additional fingerprints/users repeat steps 2–5. Your unit can enroll a maximum amount of 20 unique fingerprints. An administrator fingerprint will be required for enrolling any secondary fingerprints/users.

Step 7: Now you have successfully programmed additional fingerprints/users.

»» Opening Safe Using Biometric Swipe Scanner

Step 1: Press the Start button at the top of the scanner to activate the unit. The unit will beep once and the indicator light will begin to flash green. The unit scanner is now activated and ready to read your fingerprint.

Step 2: Using any previously enrolled finger, place your finger at the top of the scanner and swipe in a downward motion until the entire fingerprint has crossed the biometric scanner.

Step 3: Your unit will open.

***If the indicator light flashes green and red then your fingerprint swipe was not accepted and you will need to try again.**

»» Installing Your SpeedVault

SpeedVault must be mounted at a 90° angle as the door is gravity operated. The unit can be mounted from the left, right or back side using the provided mounting holes.

Step 1: Select a location to mount the unit.

Step 2: Secure the Mounting Bracket to desired location by fastening the wood screws through the wall mounting holes.

Step 3: After securing the Mounting Bracket, remove the two thumbscrews located on the bottom of the closed unit.

Step 4: Unlock the unit with the backup key and remove the drop down compartment from the shell of the unit.

Step 5: Secure and fasten the shell of the unit to the Mounting Bracket by using the 3 woodscrews provided.

Step 6: Reinstall the removed drop down compartment to the shell and restore the small bottom bracket with the thumbscrews.

Step 7: Your unit is now installed.

»» Deleting Users/Resetting the Unit

Step 1: Open the unit with the backup keys provided or by the biometric scanner and locate the Delete button on interior roof of the unit.

Step 2: Press and hold the Delete button.

Step 3: While still pressing the Delete button, press and release the Start button located on the keypad. Continue to hold the Delete button until the indicator light stops flashing green and red. Once the indicator light has stopped flashing, release the Delete button. If the indicator light flashes red and beeps once, this indicates the safe has already been reset.

Step 4: Now you are ready to reprogram your unit.

***If you do not reprogram your safe, it will remain in Demo mode and will automatically open with the push of the Start button. Individual users cannot be deleted from the unit. All users will be deleted together during this process.**

Safe Feature Section Biometric Unit Only

»» Low Battery Warning Indicator

Step 1: When you enter the correct combination and the battery is low, the indicator light will flash red and beep six times. Depending on the low battery level, the unit may sound when releasing the lock. If the battery level is too low, the indicator light will start to flash red and beep continuously until the battery is removed from the unit. If the battery in the unit is completely depleted, you will hear only a light humming sound.

Step 2: Replace battery by using steps in section labeled "Battery Installation".

***You must be opening your unit in order low battery indicator to alert you.**

»» Installing Bumper Bracket

Step 1: Locate the bumper bracket installation holes on the bottom of the unit.

Step 2: Once located, align the Bumper Bracket with the installation holes.

Step 3: Proceed to securing fasten the Bumper Bracket to the unit with the provided screws and screw driver.

Step 4: You have successfully installed the Bumper Bracket.

»» Mute Button Feature

This feature turns audio for unit off and on.

Step 1: Open the unit and locate the Mute button on the interior roof of the unit.

Step 2: Press and hold the Mute button for three seconds. While holding the mute button, the indicator light will remain solid red. When the indicator light flashes green and beeps 3 times this will indicate a successful activation.

Step 3: Now you have successfully activated/deactivated the mute feature.

»» Internal Courtesy Light

• The interior courtesy light feature becomes activated for five seconds after every time the safe door opens. This feature allows you to have a clear view of the interior and all the safe contents.

Safes, Accessories and More!!!

Loving your new GunVault safe and wanting to purchase more?

Check out our website www.GunVault.com for special promotions, safes, accessories and more information.

Safe Categories:

- Digital Safes
- Biometric Safes
- AR Safes

Accessories:

- Security cable
- MagVault

Vital Information:

- Downloadable manuals
- How-to video tutorials
- Warranty registration
- Frequently asked questions
- And MORE



SCAN QR CODE TO VISIT OUR WEBSITE
FOR FAQ'S, VIDEO TUTORIALS, AND MORE.

Warnings

- ▲ The backup key is for emergency use only in the event of fingerprint failure or forgotten passcode.
- ▲ For Key Replacement visit the GunVault.com/key_replacement to complete the online key replacement form. In order to receive a replacement key you will need to know the key number associated with your unit. You can find this information on the unit engraved on the keyport.
- ▲ Replace the batteries once a year regardless of whether or not the low battery indication is triggered.
- ▲ The manufacture recommends that you lightly coat the door hinge spring and door latch-loop with quality oil at least once a year.
- ▲ Never spray anything into the latch mechanism for it can cause damage to the safe.
- ▲ Gunvault products delivered without a pre-arranged Return Authorization number may be returned to sender unopened, at owner expense, and fees may accrue.
- ▲ Do not try to remove the key while in the turned position. This may cause damage to the unit or key.
- ▲ The lock manufacturer highly recommends the use of either a Duracell or Energizer 9V alkaline battery with an expiration date of 5 years in the future.
- ▲ Do not mount the Vault with the door facing down, the contents may fall out when the door is opened.
- ▲ Never attempt to operate the safe with external power alone. Batteries MUST be installed before and during operation with the external power supply, in order to avoid interruption of power and loss of access codes.
- ▲ Never attempt to plug in a battery charger of any kind. Fire or explosion of batteries could result.
- ▲ Never use rechargeable batteries of any kind in a GunVault safe. Their power characteristics are not compatible with the safe.
- ▲ The AC/DC power supply specified is NOT a battery charger; it is an external power supply to be used only when batteries are installed.
- ▲ Keep backup keys and access code combination in a secure place away from children.
- ▲ Do not store backup keys inside of safe.
- ▲ Keep your safe closed and locked at all times when not in use.
- ▲ Keep a record of your key number and serial number in a secure place separate from your safe.
- ▲ Keep high-strength steel security cable in a secure place away from children.
- ▲ Children should not play with or around safe at any time.
- ▲ This safe or any other firearm storage device cannot take the place of other safety procedures including advising children of the dangers of firearms.
- ▲ The manufacturer of this product does not recommend, suggest, advise, promote or otherwise condone the ownership or use of firearms. We at GunVault believe the decision to own or use a firearm is a serious decision that should only be made by an adult who has carefully considered the risks and benefits of such a decision.
- ▲ Never drink alcohol or use drugs while operating this safe or any firearm.
- ▲ Never grab your firearm by the trigger when removing or placing into safe. Always keep your firearm safety mechanism on while stored inside the safe.
- ▲ Always follow the firearm safety rules set out by the firearm's manufacture.
- ▲ GunVault recommends that you obtain as much information as possible on firearm safety.
- ▲ Always handle firearms as if they are loaded and ready to fire.
- ▲ In order to enjoy the maximum security benefits of this safe, it must be mounted in place.
- ▲ Use of this product as a storage receptacle without mounting may compromise security of the safe.
- ▲ When installing or replacing your battery, always hold the battery connecting cap while disconnecting or attaching. Do not pull on the power cables, this could cause the power supply to become disconnected
- ▲ from the lock.

WARNINGS: This product contains DEHP, a phthalate chemical known to the State of California to cause birth defects and other reproductive harm.www.P65Warnings.ca.gov

GunVault's Exclusive 5 year Warranty

1. GunVault (the "Company") warrants to the original consumer (the "Purchaser") of any GunVault safe (the "GunVault safe") purchased after January 1, 2014 against any damage caused by fire, burglary or attempted burglary for a period of five (5) years from the date of purchase.
2. The Company warrants to the purchaser that the GunVault safe will be free from defects in workmanship and materials for a period of one (1) year from the date of purchase.
3. These warranties are not assignable or transferable to any other person.
4. Any damage to the GunVault safe as a result of misuse, tampering, abuse, neglect, accident, improper installation, modification, unauthorized service, destruction, or the alteration of the serial number, or use violate of the instructions furnished by the Company will void this warranty.
5. The sole responsibility of the Company shall be limited to the repair or replacement (in its sole discretion) of any component of the GunVault safe which fails to conform to this warranty at no cost to the purchaser for the period of the warranty.
6. Contact the Company directly to obtain service under this warranty. If it becomes applicable to send a defective product to the Company, a Return Authorization Number must first be obtained from the company. In order to obtain service under this warranty, purchaser must provide the Company with the following items (a) proof of purchase, (b) police or fire department report, (c) photographs of damaged safe, and (d) written testimonial.
7. Products shipped without prior Return Authorization and Return Authorization Number may not be accepted, and the Company will not be responsible for their disposition and/or cost of return to the owner.
8. The Company will not assume any responsibility for any loss or damage incurred in shipping. All return authorized products should include a copy of the original invoice in order for this warranty to be honored.
9. This warranty is not an insurance policy. The Company is not responsible for any manner of damage to or theft of the Purchaser's GunVault safe or its contents.
10. We recommend that the warranty registration be completed online in order to validate this warranty.
11. Any implied warranties that the purchaser may have are limited to the duration of the warranties described above. There are no further warranties that extend or apply beyond the face hereof, and the company expressly disclaims and excludes any and all warranties of merchant ability or fitness for a particular purpose. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.
12. Repair or replacement shall be the sole remedy for the purchaser under this warranty. The company shall not be liable for any direct, indirect, incidental or consequential damages, losses or expense arising from the use or misuse of the GunVault safe. Some states do not allow the exclusion or limitations of incidental or consequential damages, so the limitation may not apply to you.
13. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.



Please visit GunVault.com for Replacement Promise details*

PRODUCT REGISTRATION INFORMATION

This is not a Registration Form

To submit your warranty registration go to GunVault.com/warranty/
or call our Customer Service Department at (800) -222- 1055.

For Key Replacement visit the GunVault.com/key_replacement to complete the online key replacement form. In order to receive a replacement key you will need to know the key number associated with your unit. You can find this information on the unit engraved on the keyport.

**PLEASE FILL OUT THE SECTION BELOW AND STORE
IN A SAFE LOCATION OUTSIDE OF YOUR UNIT.**

SAFE MODEL:

PURCHASED FROM:

DATE OF PURCHASE:

SERIAL NUMBER:

(This number can be found inside unit)

KEY NUMBER:

(This number can be found on the backup keys)



Customer Support Hours:
Monday - Friday 5:00AM - 6:00PM (PST)
Saturday - Sunday 8:00AM - 12:00PM (PST)
Excluding Holidays
*Hours subject to change



This page intentionally left blank



GunVault[®]
THE ORIGINAL. SINCE 1990



For Additional Support Visit:

GunVault.com

or call our Customer Support (800)-222-1055

SAFE QUICK STRONG SMART[®]



**ALPHA
GUARDIAN**

A Safe in Every Home[®]

© 2017 ALPHA GUARDIAN

Las Vegas, NV 89119 USA

AlphaGuardian.com | GunVault.com