



i360Move Robotic Vacuum Cleaner

INSTRUCTIONS MANUAL

MV303

Please keep this instruction Manual carefully,
and read it before operating

Contents	Safety instructions	1
	Product introduction	5
	Operation introduction	9
	Product maintenance	15
	Troubles shooting	19

SAFETY INSTRUCTIONS

1. It is not allowed to dismantle the product by non-technicians without permit.
2. The product only applies the original power adapter, otherwise, it may bring damage to the product.
3. Please do not touch electric wire, socket or power adapter with wet hands.
4. Please pay attention to the cloth curtains, substances that are easy to entangle, or the user's body to ensure that not to be rolled into the driven wheel.
5. Please do not get the product close to cigarette butt, lighter or other types of flames.
6. The product is for indoor use only.
7. It is not allowed to put weight of 10kg or more or stand on the product.
8. Please do not use the product in the damp environment such as bathroom and do not use it to absorb liquid.
9. Before using the product, please remove all vulnerable goods and fragile items such as glass cup and lamp as well as the things which may entangle the side brush or block the air inlet, for example, electric wire, paper, curtain, etc.
10. Please switch it off when the product is not going to be used for a long time or transported.
11. Please check if the adapter is well connected with the socket before charging.
12. The working temperature for this product is 0°C-40°C.
13. Please remove the battery before scrap of the product.

14. Users should recover the old battery when you change the battery.

15. It is forbidden to let children, mentally retarded person or person who do not have common knowledge or experience about the domestic households without surveillance.

16. Please do not dismantle the battery by yourself. Please contact the after-sales service if you want to change the battery.

This appliance is not intended to be used by children and person with reduced physical, sensory or mental capabilities, or lack of experience and knowledge on the domestic household, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

Switch off before cleaning or maintaining the appliance


- The battery in appliance must be removed from the appliance before it is scrapped;
- The appliance must be disconnected from the supply mains when removing the battery;
- The battery must be removed and discarded according to local laws and regulations before disposal of the appliance.

This appliance batteries that are only replaceable by skilled person.

WARNING: For the purposes of recharging the battery, only use the detachable supply unit GQ12-240060 provided with this appliance


⚠ Notes Before Cleaning

- 1 WARNING:** Do not use your i360Move on wet surfaces or surfaces with standing water.




Before using the product on a rug with tasseled edges, please fold the rug edges under.

2



Remove power cords and small objects from the floor that the robot could be obstructed by, and tidy up the area to be cleaned by putting furniture, such as chairs, in their proper place.




3



It may be necessary to place a physical barrier at the edge of a drop to stop the unit from falling over the edge.


Product Introduction

- ① Main Unit
- ② Charging Dock
- ③ Power Adapter
- ④ Side Brush
- ⑤ Remote Control
- ⑥ High-Efficiency Filter
- ⑦ Manual Instruction



Product Introduction

Illustration of the main unit





Brush Roller

Bottom cover of the main unit


Universal Wheel

Charging Connector

charging Socket



Dust Bin




Brush Roller

Cover

Brush Roller


Charging Dock



Power Indicating Light

Upper Cover


Power Outlet



Operation Instructions


Illustration of the Main Unit and Remote Control

Display screen



Firstly switch the "On/Off" button on unit body, indicator "⏻" light on cover flash blue and your i3 robot is ready for cleaning.
 Press the "⏻" light on machine middle cover, to start the operation of cleaning or stop the operation of cleaning.
 The signal information of "⏻" indicator light as below.
 Switch the "On/Off" button, your i3 robot is ready for cleaning and indicator light shows blue color, and the light will shut off if no operation in 30 min.
 Robot system reset, the light will quick-flash blue for 7 seconds.
 Press the "⏻", the light flash blue for 3 times, then start to cleaning and the light keeps in blue color.
 When in low battery level, the "⏻" light will flash red color slowly.
 When back to charging dock and start charging, the "⏻" light will keep flash blue color slowly, the light will keep in blue color once full-charged.
 Once meet any problems, the "⏻" indicator light will flash red color quickly.

Remote control



1. LCD Display
2. Direction Control Buttons
3. Start / Stop Button
4. Time Schedule Button
5. Return To Charge Mode Button
6. Mode Settings Button
7. Current Time Setting Button
8. Spot Cleaning Mode Button


The operation of remote control is similar as operation on TV remote, press the buttons and control your i3 cleaner directly. Firstly switch the On/Off button on your i3 robot's body and robot is ready for cleaning:

1. ⏻ Press the "⏻" button and hold for a while to start the setting of time. Press the direction arrows to set times and finally press the "⏻" button to save setting.
2. ⏻ Shortly press "⏻" button to start or pause the cleaning of your i3 robotic cleaner.
3. 📍 Press "📍", to start spot deep cleaning for specific area.
4. 🔄 Press the "🔄" button to change the cleaning mode,
 MODE1 :Edge cleaning ;
 MODE2 :Zone cleaning;
 MODE3: Auto cleaning;
 MODE4:Zigzag cleaning
 Kindly note that there will have a pause if you change MODE4 to MODE1; more details,please see the page 12 of the manual instruction.
5. 📅 Shortly press the "📅" button to check the scheduled cleaning, and long press the button for setting of scheduling, more details, please see page 11 of this manual instruction.
6. 🏠 Press "🏠" button to order your i3 robot back to charging dock.
7. ⬆️⬇️⬆️ Press the direction arrow keys to control the cleaning path of your i3 robotic cleaning.

⚠️ Cautions


Install the battery to remote control before operations, or take the battery out of remote if long time no usage of remote.

- The types of batteries that may be used;
- See following procedures to remove and insert the batteries(AAA 1.5V)
- Non-rechargeable batteries are not to be recharged;
- Different types of batteries or new and used batteries are not to be mixed;
- Batteries are to be inserted with the correct polarity;
- Exhausted batteries are to be removed from the appliance and safely disposed of;
- If the appliance is to be stored unused for a long period, the batteries should be removed;
- The supply terminals are not to be short-circuited.



Assemble the battery to remote control body

Push and take out the battery cover under remote body, fit 2pcs battery (AAA 1.5V battery) into the battery container in right direction, cover the remote control body with battery cover.




Discharge the battery from remote control body

Push and take out the battery cover under remote control body, discharge the 2 pcs AAA battery from the battery container, cover the remote control body with battery cover.

Operation Instructions


Caution and Room Preparation before Operating Your i3 Robot.

01. Put the charging dock on the ground against the wall and remove all the obstacles 2-3 meters in front of the dock as shown in the figure below.



02. If your i3 robot is in the power-off state, please switch it on.

03. You can charge your i3 robotic cleaner by the following two ways.
- Plug the power adapter directly on your i3 robotic cleaner with the other end connected with power as shown in the pic.a.
 - Please press “⏻” remote control to make your i3 robotic cleaner back to charging dock by itself as shown in the pic.b.



Operation Instructions

Charging

⚠ Caution

- When your i3 robotic cleaner is in charging, the “⏻” indicator light will flash blue color slowly.
- When the charging is completed, the “⏻” indicator light will keep in blue color.
- When the power is not enough in standby mode, your i3 robotic cleaning will send out a voice message “please charge” and “⏻” indicator light will become red color.
- When the power is not enough in the working model, your i3 robotic cleaning will stop cleaning and look for charging dock automatically and “⏻” indicator light flash red color.

Methods for extending the lifetime of the battery:

- Please charge your i3 robotic cleaner for 12 hours for the first use.
- When the power is not enough, please charge it immediately.
- When the cleaning is finished or the power is too low, your i3 robotic cleaner will start to return the charging dock automatically.
- If your i3 robotic cleaner will not be used for a long time, please charge it fully, take the battery out and keep it in the dry and ventilated place.
- If your i3 robotic cleaner is not used for 3 months, please charge it for 12 hours at one time.

Operation Instructions

Reservation Schedule Cleaning Settings

- 1 Make sure your i3 robotic cleaner is in Standby or Charge state, and then long press the "Ⓜ" button on the remote control, the remote control to enter the schedule setting mode;
- 2 At this point the remote control display appears flashing numbers, change the flashing number by press up and down button, set a number by left and right buttons to move to the next number to be set.
- 3 After setting the remote control at your i3 robotic cleaner, press the remote control "⏻" key, the success of the reservation machine will display the corresponding appointment time.

Note

The current setting is 8:00 AM. The remote control setting value is 01:00. After the setting is successful, your i3 robotic cleaner will start working after 1 hour. Your i3 robotic cleaner starts to work at 9 o'clock and will start working at 9 o'clock everyday.

Cancel the schedule cleaning settings

Make sure your i3 robotic cleaner is in Standby or Charge state, and then long press the "Ⓜ" button on the remote control, the remote control to enter the schedule setting mode; press the "⏻" button again. (If the wiring harness is 00:00, the reservation is canceled, otherwise please press "⏻" key once)


Note

Setting time, please long press "Ⓜ" button to set the time, press the left& right direction button to switch the hours/minutes; and up/down direction button to change the hours/minutes; press "⏻" to exit the time setting


Operation Instructions

Introduction Of The Cleaning Modes

- a. When press "Ⓜ", the remote control displays "1", your i3 robotic cleaner will enter to the edge cleaning, cleaning along with the obstacle.




- b. When press "Ⓜ" the remote displays "2", your i3 robotic cleaner will enter the zone cleaning, and start cleaning in a specific areas within a scope of 2*2m.



- c. When press "Ⓜ" the remote control display "3", your i3 robotic cleaner will enter auto cleaning; robot starts 2 meters cleaning and then turn a auto direction.

- d. When press "Ⓜ" the remote control display "4", your i3 robotic cleaner will enter Zigzag mode, in this mode, robot will clean in "z" way.




Product Maintenance


Side Brush

Cleaning of side brush

01. Check if there is any damage or foreign objects in the side brush.
02. Clean the side brush with cleaning tools or cloth.
03. If the brush is curled or deformed, remove and put it in the warm water for about 5 seconds.
04. If the brush is broken and cannot be used, please change it immediately.



Cleaning of brush roll assembly : Remove the brush roll assembly from the machine and take the brush roll out. Clean the brush roll and the cover with cleaning tools or cloth as shown in the figure as below. (The brush roll can be washed with water)



Caution


1. After washing, re-install the dried roller brush as per the original dis-assembly sequence.

Product Maintenance


Cleaning of the Dust Bin and Filter

Please clean the dust bin after each time of use according to the steps shown below.


- A. Press the "  " button in the middle of the upper cover to open the middle cover.




- B. Take the dust bin out.




- C. Take out the high-efficiency filter.



- D. Open the dust bin cover and take the primary filter out.




- E. Dump the dust bin.




Product Maintenance

Cleaning Of The Dust Bin And Filter

F. Wash the dust bin and the primary filter and then clean the high-efficiency filter with brush.



G. Reinstall the primary filter and the high-efficiency filter into the dust bin.




⚠ Caution

- a. It is recommended to wash the filter after it is used for 15-30 day once. The lifetime of the high-efficiency filter is 24 months.
- b. Before installation, please make sure the filter is dry.
- c. Both the high-efficiency filter and the primary filter are all replaceable.
- d. Please do not put the filter under the sunlight.


Product Maintenance

Cleaning Of The Sensor And Wheels

Cleaning of the sensor and wheels : Clean the sensor and wheels with cleaning tools or cloth as shown below.



Cleaning of the charging connector : Clean the charging cradle and the charging connector on the main unit with cleaning tools or cloth as shown below.



TROUBLES SHOOTING

Voice Notice/Problems	Possible reasons	Solution
Please turn on the power switch	Power switch is not power on when charging	Switch on the power button
Please put the machine in a safe place	Machine is not on floor, or its wheel falls down. Sensors covered by dusts	Put the machine in a safe floor Check the sensors hole, and remove all the dusts.
Wheel overload	Left and right wheel jammed by cables or ropes Machine trapped by obstacles	Remove the obstacles winded on wheels Take out the machine from obstacles
Please install dustbin	No dustbin in machine, Dustbin is incorrect installed	Check and fit the dustbin into machine. Take out and reinstall the dustbin into machine
Side brush fault	Left side brush or right side brush jammed by dusts, or obstacles	Remove the dusts or obstacles jammed on brush
Signal-short	Hair or other debris jammed the roller and cause Overload on roll	Remove the hairs or other debris on roller brush
Front bumper fault	Front bumper does not reset to position. Front bumper jammed by obstacles	Check out the bumper function if it can trigger back, and reset to position Machine trapped in obstacles, take it out of obstacles.
Please Charge	Battery in unit machine is in low level power	Press the charging to charge the machine. Machine will get back to station for charging automatically

WARNINGS ABOUT BATTERY INSIDE UNIT BODY



SAFETY
WARNING

You must not remove (or attempt to remove) the battery incorporated in this product on your own. To replace the battery, you must contact your service provider or an independent qualified professional. These instructions have been prepared for the exclusive use of your service provider or independent qualified professional.

FOR YOUR OWN SAFETY, DO NOT ATTEMPT TO REMOVE THE BATTERY ON YOUR OWN OR DISPOSE OF IT IN FIRE. DO NOT DISASSEMBLE, CRUSH OR PUNCTURE THE BATTERY.

REMOVAL OF BATTERY INSIDE UNIT BOY

- 1.Remove the screws on battery cover with a screw driver.
- 2.Remove the battery cover.
- 3.Grasp the insulating tape at two sides of the battery and lift the battery.
- 4.Unplug the wire connector that links the battery and robot.



Correct disposal of batteries in this product

(Applicable in countries with separate battery return systems.)

The marking on the battery, manual or packaging indicates that the battery in this product should not be disposed of with other household waste. Where marked, the chemical symbols Hg, Cd or Pb indicate that the battery contains mercury, cadmium or lead above the reference levels in EC Directive 2006/66.

The battery incorporated in this product is not user replaceable. For information on its replacement, please contact your service provider. Do not attempt to remove the battery or dispose it in a fire. Do not disassemble, crush, or puncture the battery. If you intend to discard the product, the waste collection site will take the appropriate measures for the recycling and treatment of the product, including the battery

PRODUCT PARAMETER

Items	Parameter
Diameter	350 mm
Height	97 mm
Net weight	4.5 kg
Voltage	14.4 V=
Battery	Ni-MH 2000 mAh
Dust bin	0.35 L

Item	Parameter
Charging type	Manual / Auto
Cleaning mode	Auto, Edge, Spot, Zigzag Zone
Charging time	4-6 hours
Cleaning time	70 minutes
Button type	Touch button

Warranty Agreement

Covered Product:

Modd Vacuum Cleaners:

Model Number: MV101, Serial Number: CUV117

Model Number: MV202, Serial Number: CUV118

Model Number: MV303, Serial Number: CUV119

Buyer:

Name: _____

Address: _____, _____, _____

Limitation of Damages

In no event shall Cecibon Inc be liable for consequential damages for breach of this warranty.

Some States do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to the buyer.

Warranty Coverage

Cecibon Inc warrants the Covered Product to be free of all defects in material and workmanship for 1 year from date of purchase. This warranty extends to the original buyer (only or and each successive buyer within the warranty period).

Within the period of this warranty, Cecibon Inc will repair or replace, free of charge; any part proving defective in material or workmanship. All warranty repairs and service must be performed by an authorized Cecibon Inc technician, or at an authorized Cecibon Inc service facility.

All expenses related to replacing or repairing a defective part under this warranty shall be assumed by Cecibon Inc except for the following expenses, which shall be assumed by the buyer:

Shipping charges:

Buyer will be responsible for any initial shipping and insurance charges if the defective product(s) must be shipped for warranty service or warranty evaluation; however, Cecibon Inc or Cecibon Inc Authorized Warranty Station will pay the return shipping charges if repairs are covered by the warranty. When returning parts for repair, you must include the model, type and serial number located on the on the vacuum. If any product submitted for warranty service is found to be ineligible, an estimate of repair cost will be furnished, and the repair performed only if requested by the owner and upon receipt of payment or acceptable arrangements for payment.

Warranty Exclusions

This warranty does not apply to any costs, repairs, or services for the following:

1. Service calls to correct the installation of the Covered Product, or to explain the usage of the product to the buyer.
2. Repairs necessitated by use other than normal home use.
3. Damage resulting from misuse, abuse, accidents, alterations, or improper installation.
4. Corrective work necessitated by repairs made by anyone other than a Cecibon Inc authorized service technician.

Further limitations and exclusions:

Any warranty that may be implied in connection with your purchase or use of the vacuum, including any warranty of Merchantability or any warranty of Fitness For a Particular Purpose is limited to the duration of this limited warranty. Some states do not allow limitations.

How to Obtain Warranty Service

b. If warranty repairs are to be made at an authorized service center:

The buyer should carefully pack the Covered Product, preferably in the original packing materials, and deliver it, together with a copy of the original purchase receipt and a description of the problem, to the following address:

Cecibon Inc
1 Blue Hill Plaza #1682
10th Floor
Pearl River, NY 10965

If the buyer sends the product by U.S. mail, we recommend that the buyer insure it and send it return receipt requested. We accept no liability for products lost or misplaced in shipment.

If Cecibon Inc does not maintain service facilities for express warranty repairs in a state and warranty repairs will not be made in the home:

Upon discovery of any defect, malfunction, or nonconformity in the Covered Product, the buyer may choose one of the following options for obtaining warranty service and repairs:

(a) The buyer should carefully pack the Covered Product, preferably in the original packing materials, and deliver it, together with a copy of the original purchase receipt and a description of the problem, to:

Cecibon Inc
1 Blue Hill Plaza #1682
10th Floor
Pearl River, NY 10965

If the buyer sends the product by U.S. mail, we recommend that the buyer insure it and send it return receipt requested. We accept no liability for products lost or misplaced in shipment.

(b) The buyer may return the Covered Product to the retail seller, who will do one of the following:

1. Service or repair the Covered Product to conform to the applicable warranty.
2. Direct the buyer to a reasonably close independent repair or service facility.
3. Replace the Covered Product with goods those are identical or reasonably equivalent to the warranted goods.
4. Refund to the buyer the original purchase price less that amount directly attributable to use by the buyer prior to the discovery of the nonconformity.

(c) The buyer may secure the services of an independent repair or service facility for the service or repair of the Covered Product, when service or repair of the goods can be economically accomplished and when the buyer is not furnished appropriate relief the provisions of subparagraph (b). In that event, Cecibon Inc will reimburse the independent repair or service facility for the reasonable cost of service and repair, including any cost for parts and any reasonable cost of transporting the goods or parts, plus a reasonable profit.

Notice to Buyer

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. You have the right to bring any action at law or equity to resolve disputes concerning or to enforce the provisions of this warranty.

If the buyer disagrees over either's performance under the terms of this warranty, the buyer may submit the matter for resolution to Cecibon Inc. The buyer shall not be responsible for expenses incurred in submitting a dispute for resolution under the terms of this paragraph. The buyer is required to submit any dispute for resolution under this paragraph before pursuing any legal remedies to which he or she may be entitled.

Cecibon Inc
1 Blue Hill Plaza #1682, 10th Floor, Pearl River, NY 10965

Toll Free
1.888.593.9254

Email
info@mymodd.com

PRODUCT PARAMETERS

Product Technical Parameters

Model	Rated Charging Voltage	Rated voltage	Rated Power
MV303	100-240 V	14.4 V =	20 W