

OBiWiFi Setup

This tutorial guides you through setting up your OBiWiFi Wireless Adapter with the OBi300/OBi302/OBi200/OBi202.

Step 1: Connect the OBiWiFi adapter to the OBi3xx or OBi2xx USB port and power on the OBi device.



Step 2: Only required for the OBi202. Please skip to step 3 for all other devices.

- Dial ***0 from the phone connected to the OBi202
- Enter 30#
- Press 1 to Enter a New Value
- Press 1# to Enable
- Press 1 to Save

Step 3*: From a WiFi enabled device, e.g. computer, tablet or smart phone, open its network settings and connect to a WiFi network called “**OBiWiFi_Setup.**” Your browser-equipped device will automatically connect to the OBiWiFi_Setup network.

If you do not see the network, dial *27 on a phone connected to the OBi.

Step 4: Wait 30 seconds. Then, open a browser window and visit <http://192.168.10.1/wifi> or try <http://obicconnect.com/wifi>.

When prompted, enter a username and password to access the configuration webpage.

The default username is: **admin**

The default password is: **admin**

Step 5: Next, you will see a screen allowing you to select your WiFi Network Name (SSID) from a drop down list and (if necessary), a WiFi Network Password. Click the Connect button to complete the setup. If the SSID is not on the drop down list, choose "Other network", and enter the SSID of your wireless router.

Allow 30 seconds for OBiWiFi adapter to connect to your wireless network. If successful, the OBi's power LED should turn from blinking green to steady green. Note: You can also verify if OBiWiFi is working properly by checking if the OBi device has acquired a valid IP address (dial ***1 to listen to the IP address).

*(Alternatively, if your OBi device has a LAN port, you may connect the OBi by ethernet cable to your computer. Proceed to step 3.

