

MODEL MTL3 MECHANICAL TIMER OPERATING INSTRUCTIONS

NOTE: Turning the knob clockwise sets the timer and winds the alarm. The further the knob is initially turned toward the 60 minutes, the longer the alarm will ring after reaching 0.

1. Turn knob clockwise to 30 minutes. This will assure an adequate alarm ring time.
2. To set a time between 0 and 30 minutes-turn the knob back to the desired time.
3. To set a time between 30 and 60 minutes-turn the knob forward to the desired time.
4. The timer will start to count down, and the alarm will sound when the pointer reaches 0.

5 Year Limited Warranty: Any instrument that proves to be defective in material or workmanship within five years of original purchase will be repaired or replaced without charge upon receipt of the unit prepaid at the address listed below. This warranty does not cover damage in shipment or failure caused by tampering, obvious carelessness or abuse.

Component Design
Northwest, Inc.
P.O. BOX 10947
Portland, OR 97296
Info@cdnw.com
www.cdnw.com