

Repeater® 25 Instructions

The Zircon Repeater® 25 combines a compact tape measure with the convenience of a digital voice recorder. Repeater 25 records up to 8 seconds of messages.

Recording Messages

1. Rewind the recorder by pressing REW.
2. Press and hold REC while speaking into the microphone. Red LED shows the unit is recording.
3. When finished speaking, release REC.
4. Repeat as desired until 20 seconds max (LED out).

NOTE: *Pressing REW again records over previous messages*

Message Playback

1. Press REW.
2. Press PLAY.
3. Press PLAY again for next message.

The Tape Lock

Slide the tape lock down to lock tape. To release, slide the tape lock up.

Replacing the Batteries

1. Remove screw from battery door.
2. Slide the door in the direction of the arrow.

3. Replace with four LR44 batteries.

4. Replace door and screw.

Removing the batteries will not erase any previously recorded messages.

Technical Specifications

Size: 3.25 in. H x 3.10 in. W x 2.05 in. D
(8.3 cm x 7.8 cm x 5.2 cm)

Weight: 13.3 oz (377 g) with battery

Battery Type: 4 LR44 —
1.5 V Alkaline button cells (included)

Battery Life: 1500 5-second playbacks

Microphone Sensitivity: 62dB +/- 3dB

Frequency Response: 50 Hz — 5 kHz

Tape Width: 1 inch (2.5 cm)

Record Time: 20 seconds

LIMITED 1 YEAR WARRANTY

Zircon Corporation, (Zircon) warrants this product to be free from defects in materials and workmanship for one year from the date of purchase. Any in-warranty defective product returned to Zircon*, freight prepaid with proof of purchase date and \$5.00 to cover postage and handling, will be repaired or replaced at Zircon's option. This warranty is limited to the electronic circuitry and original case of the product and specifically