



USER GUIDE

PH-TWS01 /
TRUE WIRELESS EARBUDS WITH MICROPHONE
AND CHARGING CASE

WELCOME

Thank you for purchasing Photive PH-TWS01 and
welcome to the Photive family!

TABLE OF CONTENTS

PACKAGE	3
FUNCTIONS	4
CHARGING	5
PAIRING	7
OPERATION INSTRUCTION	9
SPECIFICATION	12
HOW TO WEAR	13
WARRANTY INFORMATION	15
FCC INFORMATION	17

PACKAGE

1. Photive PH TWS01 earbuds



2. Charging Case



3. USB charging cable




4. Eartips



EARTIPS

We have included 4 sets of eartips. Depending on the size and shape of your ear canal, use the one that fits you best. To replace the ear tips, simply remove them to replace.

FUNCTIONS



1. MFB(multifunction button)
2. Indicator light and MIC
3. Charging contact point

4. Charging indicator
5. Micro USB charging port


CHARGING (BASE)

The Photive TWS01 includes a charging base. This can charge your earbuds approximately 4 - 5 times.

Charge the base by using the supplied Micro USB cable and connect to a standard USB charger.

Note: Most USB chargers are compatible with Photive TWS01. For optimal AC charging, please use a 1.0A USB charger.

The Charging Base LED will turn red as it's being charged. Once complete the LED indicator will turn off.



CHARGING (EARBUDS)

Place the headset (L) and (R) to the corresponding position in the bottom of charging base, close the charging base tightly.



The indicator light of the headset will turn red when being charged and will turn off automatically after being fully charged



Note: Once the earbuds are placed in the charging base, they will automatically turn off and start to charge.


IMPORTANT

If the charging base has no power, the earbuds will not turn off automatically. Please ensure the charging base has power in order to function properly

PAIRING

Pair (R) and (L) to each other

The Photive TWS01 earbuds are paired to each other automatically from the factory.



In the event they need to be reconnected.

In OFF mode, press MFB for 2 seconds to power on and wait for 10 seconds, the two headsets will enter TWS pairing mode automatically. The two headsets will connect to each other.

PAIRING TO YOUR DEVICE

1. Pick up the two headsets from the charging base to power on and wait for 10 seconds, the two headsets will automatically pair to each other. The right earbud (R) will flash red and blue indicating the headset is in pairing mode ready to connect to your device.



2. Open your devices Bluetooth setting and search for "Photive TWS01"
3. Select "Photive TWS01" and your done

FACTORY RESET

In the event you want to delete all pairing records reset the earbuds. Follow below instructions.

In OFF mode, press MFB (R) and (L) for 10 seconds (OFF mode → ON mode (2 seconds) → Delete pairing records (10 seconds)), until you hear 3 beeps, and the red / blue light flashes twice at the same time.


OPERATION INSTRUCTION

Turning ON / OFF

Method 1.

In OFF mode, press and hold MFB for 2 seconds to turn on.

In ON mode, press and hold MFB for 5 seconds to turn off.



Method 2.

Pick up the headsets from the charging base to turn on automatically.
Put them back and close the charging base to turn off automatically.



OPERATION INSTRUCTION

Music pause / playing

In standby mode, shortly press MFB to play music.

In music playing mode, shortly press MFB to PLAY music, press MFB again to PAUSE music.



Answering / ending a call / headset(R)

In standby mode or call mode, you can answer / end the call by shortly press MFB of the headset(R).



Rejecting a call

Press and hold MFB of headset(R) for 2 seconds to reject the call, the speaker prompts "beep" twice and "call reject".



OPERATION INSTRUCTION

Last number redial / Heatset(R)

In standby mode or call mode, shortly press MFB twice to redial the last phone number. The speaker will prompt “beep” twice and “redial”.



Two-call handling / Heatset(R)

(Only supported with mobile phones who have ability of handling two phones.)

When you are answering a call and there is another call coming :

1. Press and hold MFB of headset(R) for 2 seconds to end the current call and answer another one.
2. Shortly press MFB of headset(R) once to answer another call and hold on the current one.
3. After the above operation “2” settled, shortly press MFB of headset(R) to transfer one call to another.

Note: All the above operations have to respect the precondition that phone supported Bluetooth hands free profile V1.5 and phone are running under call holding function (network services) from telecom.

SPECIFICATION

Bluetooth Version:	V4.2
Bluetooth Profiles Supported:	HSP, HFP, A2DP, AVRCP, TWS
Audio Decoding Protocol:	SBC, AAC
Transmission Power:	Class 2
Operation Range:	Up to 10 meters
Frequency Range:	2.4GHz - 2.48GHz
Battery of Headset:	45mAH Li-polymer Battery X2
Charging Voltage of Headset:	5V
Charging Time of Headset:	About 1 hour
Battery of Base	460mAH Li-polymer Battery
Charging Voltage of Base:	5V
Charging Time of Base:	About 2 hour
Charging Headset Times from Charging Base:	4 - 5 times
Charging Base Supply Power for Headset Music Play Time:	About 10 hour
Music Playing Time:	Up to 2.5 hours
Talk Time:	Up to 3 hours
Standby Time:	Up to 100 hours
Dimensions of Charging Base(mm):	L69 x W30 x H29.5
Dimensions of Headset(mm):	L23.5 x W17.1 x H22.4
Weight (one headset):	About 4.6g
Total Weight:	About 28.5g

*The time mentioned above may vary due to user's operation mode and device settings.


HOW TO WEAR YOUR PH-TWS01

The PH-TWS01 earbuds feature premium components and sound quality for an optimal listening experience. In order to achieve optimal sound and comfort, please read the instructions how to select a combination of eartips.

Note Your ear canals are not a carbon copy of each other. It's common for a user to wear a medium ear tip on one ear and a larger one in the other. Experiment: the goal is to produce a the best possible "seal" while achieving comfort.

EARTIPS

We have included 4 sets of eartips. Depending on the size and shape of your ear canal, use the one that fits you best. To replace the eartips, simply remove them and replace.



HOW TO WEAR YOUR PH-TWS01

Step 1



Place the headset into the concha.




Step 2

Slightly rotate headset until it is firm.



Step 3

Ensure the earpiece is secure and fits snug.



WARRANTY INFORMATION

This Product (including any accessories included in the original packaging) as supplied and distributed in new condition, is warranted by Photive to the original consumer purchaser against defects in material and workmanship ("Warranty") as follows:

1. **LABOR** : For a period of one (1) year from date of original consumer purchase, if this Product or any part is determined by Photive, or a Photive authorized service provider, to be defective, Photive will repair or replace the Product with new or refurbished product of similar or better quality, at Photive's option, at no charge to the original consumer, or pay the labor charges to any Photive authorized service provider. After the one (1) year Warranty period, you must pay for all labor charges.
2. **PARTS** : For a period of one (1) year from the date of original consumer purchase, Photive will supply, at no charge to the original consumer, new, rebuilt or refurbished replacement parts in exchange for defective parts, or will replace the Product with new or refurbished product of similar or better quality, at Photive's option, at no charge to the original consumer. After the one (1) year Warranty period, you must pay for the costs of all parts.
3. **SHIPPING COSTS** : Notwithstanding the foregoing, the original consumer is responsible for any shipping charges incurred to ship the Product or part(s) to Photive or to an Photive authorized customer service provider, for diagnosis, repair or replacement.

Please have your model number available along with your date of purchase.

To receive Warranty service, the original consumer purchaser must contact Photive for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the Product is within the applicable Warranty period(s), **MUST** be presented to Photive, or an authorized customer service provider, in order to obtain the requested service.

For warranty & support, please visit us at

www.photive.com

EXCLUSIONS AND LIMITATIONS

This Warranty covers manufacturing defects in materials and workmanship encountered in the normal, noncommercial use of the Product, and does not cover (a) damage or failure caused by or attributable to abuse, misuse, failure to follow instructions, improper installation or maintenance, alteration, accident or excess voltage or current; (b) improper or incorrectly performed repairs by non-authorized service facilities; (c) onsite consumer instruction or adjustments; (d) transportation, shipping, delivery, insurance, installation or set-up costs; (e) costs of product removal, transportation or reinstallation costs; (f) ordinary wear and tear, cosmetic damage or damage due to acts of nature, accident; (g) commercial use of the Product; (h) modification of, or to any part of the Product. This Warranty applies to the original consumer only and does not cover products sold AS IS or WITH ALL FAULTS, or consumable (e.g., fuses, batteries, bulbs etc.). This Warranty is valid only in the United States, and only applies to products purchased and serviced in the United States. All replaced parts and products, and products on which a refund is made, become the property of the Warrantor. NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE, SHALL APPLY. THE WARRANTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON THE WARRANTOR.

REPAIR, REPLACEMENT OR REFUND OF THE ORIGINAL PURCHASE PRICE – AT THE WARRANTOR'S SOLE DISCRETION – ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER. THE WARRANTOR SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY Photive. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.

Some states do not allow the exclusion or limitation of incidental or consequential damages, or allow limitations on warranties, so the above limitations or exclusions may not apply to you. This warranty gives you specific rights, and you may have other rights, which vary from state to state.

FCC INFORMATION

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed or used in accordance with the instructions, it may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- 1** Reorient or relocate the receiving antenna.
- 2** Increase the separation between the equipment and the receiver.
- 3** Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- 4** Consult the dealer or an experienced radio/TV technician for additional suggestions.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Where shielded interface cables have been provided with the product or specified additional components or accessories elsewhere defined to be used with the installation of the product, they must be used in order to ensure compliance with FCC regulation.

THANK YOU.



© 2017 Photive Edison, NJ 08837

The Bluetooth word mark and logos are owned by Bluetooth SIG, Inc. All other trademarks and trade names are those of their respective owners. The illustrated product and specifications may differ slightly from those supplied. Made in China