

CLEARSTREAM™ MICRON

Before attaching the antenna to any surface, **TEST RECEPTION** in that area.

Connect the antenna to the TV or **digital converter box** and run a full channel scan. If reception is not as desired, move the antenna and rescan TV/**digital converter box**.









Table Top Use:



1. Place antenna into base as shown in Fig.1.
2. Tabs in base will fit into grooves on back plate of antenna. Fig.2.
3. Connect cable to TV or **digital converter box**.
4. Perform channel scan on TV or **digital converter box**. Refer to your TV / **digital converter box** owners manual for instructions.
5. If reception is not as desired move antenna and rescan the TV or the **digital converter box**.


Flush Wall Mount:

1. Remove insert from base at center holes. Fig 3 - 3a.
2. Use insert as a template to mark center mounting holes on wall. Screw hanging screws into wall and back out far enough to allow insert to attach to wall.
3. To attach insert to antenna, screw short screws provided into the back of the antenna using 2nd holes from top and bottom. Fig 4.



4. Hang antenna on the wall. 5. Connect cable to TV or **digital converter box**.
6. Perform channel scan on TV or **digital converter box**. Refer to your TV/**digital converter box** owners manual for more instructions.

Raised Wall Mount:



1. Remove insert from base at center holes. Fig 3- 3a. above.
2. Use insert as a template to mark center mounting holes on the wall.
3. Screw hanging screws into the wall and back out far enough to allow insert to attach to wall.
4. Reattach insert to base.
5. To attach insert to antenna, screw long screws provided into back of antenna using 2nd holes from top and bottom. Fig. 5.
6. Hang antenna on the wall.
7. Connect cable to TV or **digital converter box**.
8. Perform channel scan. Refer to your TV/**digital converter box** owners manual for more instructions.



Call to Learn.
1-877-825-5572

Technical Assistance is available Monday - Friday, 9am - 9pm and Saturday - Sunday, 10am - 6pm Central Time.

Troubleshooting

Problem: I'm not getting any signals at all.

Possible causes:

1. You **MUST RESCAN** your converter box or TV.

A TV must be set to the proper input source. Using the TV remote control:

- Go into the setup menu and select the proper source. It may be labeled "antenna", "air", "broadcast" or "cable off". Refer to your TV user's manual.
- Within the setup menu select channel setup or channel scan. Again, you may need to refer to your TV user's manual for exact directions.
- If the initial rescan does not bring in all desired channels, follow the double rescan procedure below:

Disconnect the antenna from the converter box or digital TV:

- Rescan the converter box or digital TV without the antenna connected. As with any scan, follow the on-screen instructions or owner's manual for your device.
- Unplug the converter box or digital TV from the electrical outlet for at least one minute.
- Reconnect the antenna to the converter box or digital TV and plug the unit into the electrical outlet.
- Rescan the converter box or digital TV one more time.

Make sure the antenna is facing the broadcast towers in your area. To locate your towers go to www.antennapoint.com or call your local TV stations.

2. You do not have a clear line of sight to your local broadcast towers. You might need to elevate and/or move your antenna. Using a taller mast may be helpful. You have found the right location for your antenna when all of your local channels appear after a subsequent rescan. Remember, rescan at every location that you try.

3. You are outside of the range of your antenna's capabilities.

Depending upon the distance between you and your local TV broadcast towers you may need a longer range antenna. Antennas Direct offers many models for this purpose.

4. If you have more than one TV connected to the antenna or if your cable line is too long (50+ feet) , you may need an amplifier.

Call our Helpline to be sure this will improve your reception. If amplification is added when NOT needed, reception problems could arise.

5. You may have loose fitting connections along your cable line.

Check ALL connections for tight fit and check all outdoor connections for moisture or corrosion.

6. Building material such as brick, metal or stucco will inhibit signal. Move your antenna near a window facing your broadcast towers

Problem: I'm receiving every channel except for one.

Possible causes:

1. You may need to rescan your TV tuner or converter box.

See item 1.

2. The channel you are not receiving may have its transmitter lower on the broadcast tower than the other transmitters and your line of sight is blocked.

Try elevating your antenna or moving it to another location.

Problem: I'm having signal breakups but I'm only two miles from the transmitter.

Possible causes:

1. Your TV may be receiving interfering signals.


A larger/stronger antenna will not necessarily solve this problem.

Consider moving the antenna making sure it is not placed near metal objects or other antennas. If this is not successful, your signal may be too strong. Call our Helpline for an analysis of your area and installation. We can offer simple solutions.

Call To Learn. Don't Return.



**For Tower Locations:
antennapoint.com**



Input On Antenna Mode



**Scanning is a Must
When in Doubt, Rescan**

HELPLINE: 1-877-825-5572

Antennas Direct Inc.
Lifetime Limited Warranty

Antennas Direct® Inc. warrants this product against any defects in materials or workmanship for as long as you own the product. No warranty claim will be honored unless at the time the claim is made you present proof of purchase from an authorized Antennas Direct Inc. dealer.

Antennas Direct Inc. will either repair or replace the defective product at no charge to you. This warranty covers parts, but does not cover any costs incurred in removal or reinstallation of the product. This limited warranty does not apply if the product is damaged or fails from: misuse, improper installation, abuse, and modification of the product as originally manufactured by Antennas Direct.

Antennas Direct Inc. will not assume any liabilities for any other warranties, expressed or implied by any other person. The foregoing shall be the sole and exclusive remedy of any person, whether in contract, tort or otherwise, and Antennas Direct Inc. shall not be liable for incidental or consequential damage or commercial loss, or from any other loss or damage as set forth above.

16388 Westwoods Business Park, St. Louis, MO 63021